



**Models: 7054-020, 7054-022  
67 Ton (60.8 Metric Ton)  
Universal Jack Tester**

08/2022 – Rev. 02

**For Spare Parts, Operations & Service Manuals or Service Needs  
Scan the QR code or visit [Tronair.com/aftermarket](http://Tronair.com/aftermarket)**



REVISION	DATE	TEXT AFFECTED
01	03/2018	Original release
02	08/2022	Modified 1.4 Specifications and Parts List

**TABLE OF CONTENTS**

	<b><u>PAGE</u></b>
<b>1.0 PRODUCT INFORMATION .....</b>	<b>1</b>
1.1 DESCRIPTION.....	1
1.2 MODEL & SERIAL NUMBER.....	1
1.3 MANUFACTURER .....	1
<b>2.0 SAFETY INFORMATION.....</b>	<b>1</b>
2.1 USAGE AND SAFETY INFORMATION .....	1
<b>3.0 ASSEMBLY .....</b>	<b>2</b>
3.1 BEAM ASSEMBLY POSITIONING .....	2
<b>4.0 TRAINING.....</b>	<b>2</b>
4.1 TRAINING REQUIREMENTS .....	2
4.2 TRAINING PROGRAM .....	2
4.3 OPERATOR TRAINING.....	2
<b>5.0 OPERATION.....</b>	<b>3</b>
<b>6.0 LOAD CELL.....</b>	<b>4</b>
6.1 MAINTENANCE.....	4
6.2 TO CHANGE DISPLAY TO INDICATE TONS .....	4
6.3 TO CHANGE DISPLAY TO INDICATE POUNDS.....	5
<b>7.0 PROVISION OF SPARES.....</b>	<b>5</b>
7.1 SOURCE OF SPARE PARTS.....	5
7.2 RECOMMENDED SPARE PARTS LISTS .....	5
<b>8.0 IN SERVICE SUPPORT.....</b>	<b>5</b>
<b>9.0 GUARANTEES/LIMITATION OF LIABILITY .....</b>	<b>6</b>
<b>10.0 APPENDICES .....</b>	<b>6</b>

This product can not be modified without the written approval of Tronair, Inc. Any modifications done without written approval voids all warranties and releases Tronair, Inc., its suppliers, distributors, employees, or financial institutions from any liability from consequences that may occur. Only Tronair OEM replacement parts shall be used.

**1.0 PRODUCT INFORMATION**

**1.1 DESCRIPTION**

The jack tester has two vertical columns connected together by a top connecting beam and installed into the base. The top connecting beam support holds a manually operated hoist which is connected to the load beam assembly. A load cell is mounted on the underside of the load beam assembly. The load beam assembly is locked in place by a pair of lock pins. The position of the beam assembly can be adjusted by removing the lock pins and using the hoist.

**1.2 MODEL & SERIAL NUMBER**

Reference nameplate on unit

**1.3 MANUFACTURER**

Columbus **Jack**/Regent  
1 Air Cargo Pkwy East  
Swanton, Ohio 43558 USA

Telephone: 614.443.7492  
Fax: 614.444.9337  
E-mail: sales@columbusjack.com  
Website: www.columbusjack.com

**1.4 SPECIFICATIONS**

With the addition of the Relief Valve Assembly this jack is derated to the capacities as noted:

- Capacity ..... 67 ton (60.8 metric ton)
- Jack Height Capability
  - Minimum ..... 8 in (20.32 cm)
  - Maximum ..... 152 in (386 cm)
- Tester Overall Dimensions
  - Height ..... 218 in (553.72 cm)
  - Width ..... 124 in (314.96 cm)
  - Depth ..... 112 in (284.48)
  - Base Height ..... 13 in (33 cm)
- Weight of Components
  - Base ..... 5250 lbs (2384.36 kg)
  - Columns ..... 600 lbs (272.16 kg) each
  - Load Beam ..... 1000 lbs (453.6 kg)
  - Connecting Beam ..... 75 lbs (34 kg)
- Electrical Requirement ..... 110 VAC, 50/60 Hz - 7054-020 only  
220/230 VAC, 50 Hz - 7054-022 only

**2.0 SAFETY INFORMATION**

**2.1 USAGE AND SAFETY INFORMATION**

To insure safe operations please read the following statements and understand their meaning. Also refer to your equipment manufacturer's manual for other important safety information. This manual contains safety precautions which are explained below. Please read carefully.



**WARNING!** — Warning is used to indicate the presence of a hazard that **can cause severe personal injury, death, or substantial property damage** if the warning notice is ignored.

**CAUTION!** — Caution is used to indicate the presence of a hazard that **will or can cause minor personal injury or property damage** if the caution notice is ignored.

### 3.0 ASSEMBLY

1. Place the base in position.



#### CAUTION!


**Make sure there is at least 24 ft (7.3 m) vertical clearance for tester assembly.**



#### WARNING!

**Use caution when working around the supported load beam.**

2. Place the load beam on the base as shown.
3. Assemble both columns into the base and install capscrews, washers and nuts. Do not tighten the nuts.
4. Assemble the connecting beam to the top of the columns.
5. Assemble the chain hoist from the connecting beam to the load beam.
6. Install adjusting screws and nuts in the bottom column support and tighten until the columns are vertical within 0.5 degrees. Tighten nuts.
7. Using the chain hoist, raise and lower the load beam to verify ease of pinning the beam to the columns.



#### WARNING!

**Make sure that the area around the jack tester is clear of objects that could hit or catch the load chain or beam assembly during operation.**



#### WARNING!

**Never walk under beam assembly if load pins are not in the locked position.**

8. Install the load cell to the bottom beam assembly and connect cable to the Digital Weight Indicator.

#### 3.1 BEAM ASSEMBLY POSITIONING



#### WARNING!

**Make sure that the area around the jack tester is clear of objects that could hit or catch the load chain or beam assembly during operation.**



#### WARNING!

**Never walk under beam assembly if load pins are not in the locked position.**

1. Raise or lower the load beam until the proper height is reached.
2. Install the lock pins and lower the hoist until the hoist chain is slack.

### 4.0 TRAINING

#### 4.1 TRAINING REQUIREMENTS

The employer of the operator is responsible for providing a training program sufficient for the safe operation of the unit.

#### 4.2 TRAINING PROGRAM

The employer provided operator training program should cover safety procedures concerning use of the unit in and around the intended aircraft at the intended aircraft servicing location.

#### 4.3 OPERATOR TRAINING

The operator training should provide the required training for safe operation of the unit.

**NOTE: Maintenance and Trouble Shooting are to be performed by a skilled and trained technician.**

To derive maximum service, it is recommended that personnel have an understanding of the equipment before attempting to operate the bead breaker. It is mandatory that the operating procedures herein be followed.

## 5.0 OPERATION

1. Turn power source "on". Permit the control box to do a self-check for approximately one (1) minute.
2. Position the beam assembly as required (Reference Section 3.4 Beam Assembly Positioning).



### **WARNING!**

**Jack must be centered and leveled under load cell to prevent side loads applied to jack tester.**

3. Center jack under the load cell.



### **WARNING!**

**Tripod jack footpads must be positioned over base I-beams.**

4. Partially extend screw extension on jack.
5. Press the N/G push-button on the control box such that NET is displayed. Ensure the display indicates zero weight by pressing the TARE button.



### **WARNING!**

**Ball may fall and cause injury to personnel or equipment.**



6. Remove ball from storage box on Load Beam and place in cup adapter on jack.
7. Close relief valve on jack and extend ram(s) until cup adapter and ball contact jack tester.
8. Extend jacks to the following height positions:  
**Single Stage Jacks:** Extend ram at least 2 in (5 cm)  
**Multi-Stage Jacks:** Extend the first (larger) stage ram fully and the second (smaller) stage at least 2 in (5 cm)  
**ColumbusJACK/Regent Rhino Series 5923:** Position jack point 8-10 in (20.32-25.4 cm) from the floor  
**ColumbusJACK/Regent Rhino Series 8398:** Position the jack point 21-24 in (53.34-60.96 cm) from the floor
9. Continue to pressurize the jack against the load cell until the desired load is indicated on the display. Set the relief valve on the jack. Upon re-checking the adjustment, the load indicated may vary + 5% of rated load. This effect is due to amount, type and length of manual pump strokes. Jacks with air pumps should be set using the air pump.
10. After completion of the test, open release valve on the jack and fully retract the jack ram(s). Replace ball in storage box, lower the screw extension completely and remove the jack from under the jack tester.

**6.0 LOAD CELL**

**6.1 MAINTENANCE**

Refer to Vishay Maintenance Manual for complete instructions on load cell maintenance and calibration. (See Appendix)

**6.2 TO CHANGE DISPLAY TO INDICATE TONS**



1. Depress "MENU" button until 

CAL MENU
-------------

 is displayed
2. Depress "EDIT" button
3. Depress 

▼
---

 until "UNITS" is displayed
4. Depress "EDIT" button
5. Depress 

▼
---

 until "TN" is displayed
6. 8.6 Depress "ENTER"
7. Depress 

▼
---

 until "CAPACITY" is displayed
8. Depress "EDIT" button
9. Using a combination of the four arrow buttons, change display to 1000
10. 8.10 Depress "ENTER" button
11. Depress 

▼
---

 until "DECIMAL" is displayed
12. Depress "EDIT" button
13. Using a combination of the four arrow buttons, change display to 100.0
14. Depress "ENTER" button
15. Depress 

▼
---

 until "COUNT BY" is displayed
16. Depress "EDIT" button
17. Using a combination of the four arrow buttons, change display to .1
18. Depress "ENTER" button
19. Depress "ESC" button
20. Readout should now indicate in tons and tenths of tons.

6.0 Load cell continued on following page.

### 6.3 TO CHANGE DISPLAY TO INDICATE POUNDS

1. Proceed as outlined in 6.2 TO Change Display To Indicate Tons with the following values:

- a. Change units to "LB"
- b. Change "CAPACITY" to "200000"
- c. Change "DECIMAL" to all the way to the right of the display
- d. For less digit fluctuations, change "COUNT BY" to 2000.

For more fluctuations and greater accuracy, change "COUNT BY" to 10

Note: This represents the pounds the unit will be counting by, either 2000, 3000, etc. or 10, 20, 30 etc.

2. Readout should now indicate in pounds.

**Note: Calibration Type for the 7054-020 is "QUICK". (Reference Figure 3-2 in Vishay Readout Appendix)**

## 7.0 PROVISION OF SPARES

### 7.1 SOURCE OF SPARE PARTS

Spare parts may be obtained from the manufacturer:

ColumbusJack/Regent

1 Air Cargo Pkwy East

Swanton, Ohio 43558 USA

Telephone: 614.443.7492

Fax: 614.444.9337

E-mail: [sales@columbusjack.com](mailto:sales@columbusjack.com)

Website: [www.columbusjack.com](http://www.columbusjack.com)



For Spare Parts, Operations & Service Manuals or Service Needs:

Scan the QR code or visit [Tronair.com/aftermarket](http://Tronair.com/aftermarket)

### 7.2 RECOMMENDED SPARE PARTS LISTS

Reference the following page(s) for Replacement Parts and Kits available.

## 8.0 IN SERVICE SUPPORT

Contact Columbus Jack. for technical services and information. See Section 1.3 – Manufacturer.

### **9.0 GUARANTEES/LIMITATION OF LIABILITY**

1. ColumbusJACK Corporation, (Seller) warrants each new product of its manufacture to be free from defects in material or workmanship, under proper, reasonable and normal use and service, and for a period of twelve (12) months after date of shipment from Seller's Swanton, OH. USA facility.
2. Where Buyer claims an alleged defect in material or workmanship and so advises Seller in writing within ten (10) days after discovery thereof, then and in such event, Buyer shall return said equipment, transportation prepaid, to the Seller, provided such return is timely and within twelve (12) months form date of original shipment. This warranty and liability of the Seller is expressly limited solely to replacement of repair of defective parts or goods, and return at Buyer's expense to Seller after find by Seller the product was defective prior to original shipment or, at the option of Seller, to making refund to Buyer of the purchase price for said product.
3. It is further expressly understood and agreed that:
  - a. THERE IS NO WARRANTY, representation of condition OF ANY KIND, express or implied, (INCLUDING NO WARRANTY OF MERCHANT-ABILITY OR OF FITNESS) EXCEPT THAT THE MATERIAL SHALL BE OF THE QUALITY SPECIFIED HEREIN, and none shall be implied by law. Except as otherwise provided herein, quality shall be in accordance with seller's specifications. Final determination of the material for the use contemplated by Buyer is the sole responsibility of Buyer and Seller shall have no responsibility in connection with such suitability, and
  - b. The Buyer's sole and exclusive remedy shall be repair or replacement of defective parts by the Seller. Should the goods, in the judgment of Seller, preclude the remedying of the warranted defects by repair or replacement, the buyer's sole and exclusive remedy shall be the refund of the purchase price, and
  - c. Seller shall not be liable for prospective profits or special, indirect or consequential damages, nor shall any recovery of any kind against Seller be greater in amount than the purchase price of the specific material sold and causing the alleged loss, damage or injury. Buyer assumes all risk and liability for loss, damage or injury to persons or property of Buyer or others arising out of use or possession of any product or part sold hereunder, and
  - d. The Seller shall in no way be deemed or held to be obligated, liable or accountable upon or for any guarantees or warranties, express or implied, or created by statute or by operation of law or otherwise, in any manner of form beyond its express agreement above set forth, and
  - e. No warranty herein shall apply to any product which shall have been repaired or altered, unless such alteration or repair has been made by Seller or where, after return to and inspection by Seller, the product is found by Seller to have been subject to misuse, negligence or accident, and
  - f. No warranty of any nature is made by Seller as to any component forming a part of the product sold and Buyer shall receive only such warranties offered by such other manufacturer pertinent to such component, and
  - g. Seller does not assume nor does Seller authorize any other person to assume for it any other liability or make any warranty in connection with the sale of its products.


The obligations of ColumbusJACK expressly stated herein are in lieu of all other warranties or conditions expressed or implied. **Any unauthorized modification of the ColumbusJACK products or use of the ColumbusJACK products in violations of cautions and warnings in any manual (including updates) or safety bulletins published or delivered by ColumbusJACK will immediately void any warranty, express or implied and ColumbusJACK disclaims any and all liability for injury (WITHOUT LIMITATION and including DEATH), loss or damage arising from or relating to such misuse.**

### **10.0 APPENDICES**

APPENDIX I Vishay Readout


### Parts List

When ordering replacement parts/kits, please specify model, serial number and color of your unit.



### Parts List

When ordering replacement parts/kits, please specify model, serial number and color of your unit.



VIEW A - SCALE: 2/1  
BACK OF LOAD BEAM TYPICAL BOTH SIDES

Item	Part Number	Description	Qty
1	7054-300	Base Weldment	1
2	7054-240	Column	2
3	7054-130	Load Beam Weldment	1
4	7054-140	Connecting Beam	1
5	7054-6	Load Cell Base	1
6	7054-170	Pin	2
7	450A6266	Quick Release Pin with Lanyard	2
8	MS21318-23	Drive Screw	2
9	450A6688	Load Cell Assembly – 7054-020	1
	EC-3451	Load Cell Assembly – 7054-022	
10	915-176	Nameplate	1
11	MS21318-13	Drive Screw	4
14	450A6369	Enclosure	1
15	450A6370	Hand Chain Hoist	1
16	450A6371	Shackle	2
17	450A6372	Steel Ball	1
18	374-38800	Hex Head Cap Screw	4
19	345-11090	Flat Washer	8
20	346-10096	Lockwasher	4
21	333-43800	Hex Nut	4
22	372-26140	Hex Head Cap Screw	12
23	333-52600	Hex Nut	14
24	346-10048	Lockwasher	3
25	372-26220	Hex Head Cap Screw	1
26	372-26680	Hex Head Cap Screw	2
27	371-20220	Hex Head Cap Screw	4
28	346-10032	Lockwasher	4
29	371-12060	Hex Head Cap Screw	4
30	346-10016	Lockwasher	4





## **APPENDIX I**

### **Vishay Readout**



# Table of Contents

<b>SECTION I General Information .....</b>	<b>Page 1-1</b>
<b>1.1 Instrument Description .....</b>	<b>Page 1-1</b>
1.1.1 Introducing the Plug-n-Weigh Concept .....	Page 1-1
1.1.2 The Safe-Weigh Software System .....	Page 1-1
1.1.3 The LCp-100 Front Panel .....	Page 1-1
1.1.4 Main Configuration Flow Diagram .....	Page 1-3
1.1.5 Serial Communication .....	Page 1-3
<b>1.2 OPTIONS .....</b>	<b>Page 1-3</b>
1.2.1 Mounting Options .....	Page 1-3
1.2.2 Internal Summing Junction Board .....	Page 1-3
1.2.3 Analog Output .....	Page 1-3
1.2.4 Allen-Bradley Remote I/O Network Interface .....	Page 1-3
1.2.5 Modbus RTU Protocol .....	Page 1-4
1.2.6 Fisher Provox Protocol .....	Page 1-4
1.2.7 Modbus Plus Protocol .....	Page 1-4
<b>1-3 LCp-100 SPECIFICATIONS .....</b>	<b>Page 1-4</b>
<b>1.4 ORDERING INFORMATION .....</b>	<b>Page 1-5</b>
<b>1.5 WARRANTY POLICY .....</b>	<b>Page 1-5</b>
<b>1.6 FIELD ENGINEERING .....</b>	<b>Page 1-5</b>
<b>SECTION II INSTALLATION .....</b>	<b>Page 2-1</b>
<b>2-1. INTRODUCTION .....</b>	<b>Page 2-1</b>
<b>2-2. MOUNTING .....</b>	<b>Page 2-1</b>
2.2.1 Standard Unit Mounting .....	Page 2-1
2.2.2 Optional NEMA 4/4X Enclosures .....	Page 2-1
<b>2.3 ELECTRICAL CONNECTIONS .....</b>	<b>Page 2-3</b>
2.3.1 The LCp-100 Rear Panel .....	Page 2-3
2.3.2 Transducer Signal Inputs .....	Page 2-3
2.3.3 Mains (ac) Power .....	Page 2-3
2.3.4 Serial Communication .....	Page 2-4
2.3.5 Analog Output (Optional) .....	Page 2-4
2.3.6 Digital (Remote) Inputs .....	Page 2-4
2.3.7 Allen Bradley Remote I/O (Optional) .....	Page 2-5
2.3.8 Summing Junction Box Considerations .....	Page 2-5
2.3.9 Internal 306 Junction Board (Optional) .....	Page 2-5
2.3.10 Modbus Plus .....	Page 2-6
<b>SECTION III Set-Up and Calibration .....</b>	<b>Page 3-1</b>
<b>3.1 INTRODUCTION .....</b>	<b>Page 3-1</b>
<b>3.2 SET-UP SYSTEM PARAMETERS .....</b>	<b>Page 3-1</b>
3.2.1 Display Units .....	Page 3-1
3.2.2 Capacity .....	Page 3-1
3.2.3 Decimal Point Location .....	Page 3-1
3.2.4 Output .....	Page 3-1
3.2.5 Front Panel Display Counts .....	Page 3-1

<b>SECTION III (continued)</b>	
<b>3.3 SYSTEM CALIBRATION .....</b>	<b>Page 3-1</b>
3.3.1 Quick Type Calibration .....	Page 3-1
3.3.2 Deadload Calibration .....	Page 3-1
3.3.3 Keypad Calibration .....	Page 3-1
<b>SECTION IV Dynamic Digital Filter .....</b>	<b>Page 4-1</b>
<b>4.1 GENERAL .....</b>	<b>Page 4-1</b>
4.1.1 Digital Averaging .....	Page 4-1
4.1.2 Band Selection .....	Page 4-1
4.1.3 Filter Set-Up Procedures .....	Page 4-1
<b>SECTION V Front Panel Display Functions .....</b>	<b>Page 5-1</b>
<b>5.1 FRONT PANEL FUNCTIONS .....</b>	<b>Page 5-1</b>
5.1.1 Horizontal Bar Graph .....	Page 5-1
5.1.2 Vertical Bar Graph .....	Page 5-1
5.1.3 Alarm Status Annunciators .....	Page 5-1
5.1.4 Configuring The TARE Key .....	Page 5-1
5.1.5 Configuring The ZERO Key .....	Page 5-3
<b>5.2 VIEW mV/V SIGNAL .....</b>	<b>Page 5-3</b>
<b>SECTION VI Analog Output and Serial Communication .....</b>	<b>Page 6-1</b>
<b>6.1 ANALOG OUTPUT CONFIGURATION (Optional).....</b>	<b>Page 6-1</b>
6.1.1 Output Definition .....	Page 6-1
6.1.2 Set-Up Procedure .....	Page 6-1
<b>6.2 SERIAL COMMUNICATION .....</b>	<b>Page 6-1</b>
6.2.1 Transmit Only Output Formats .....	Page 6-1
6.2.2 Full/Half Duplex Bi-Directional Interface .....	Page 6-4
6.2.3 Modbus Protocols (Optional) .....	Page 6-4
6.2.4 Fisher Rosemount - Provox Protocol (Optional) .....	Page 6-4
<b>6.3 ALLEN-BRADLEY RIO (Optional) .....</b>	<b>Page 6-4</b>
<b>SECTION VII System Diagnostics.....</b>	<b>Page 7-1</b>
<b>7.1 OVERVIEW .....</b>	<b>Page 7-1</b>
7.1.1 Diagnostic User .....	Page 7-1
7.1.2 Diagnostic Version .....	Page 7-1
7.1.3 Diagnostic Recall .....	Page 7-1
7.1.4 Selecting Limits .....	Page 7-1
7.1.5 Front Panel Key Test .....	Page 7-1
7.1.6 Check Remote Inputs .....	Page 7-1
7.1.7 Test/Verify The Analog Output .....	Page 7-1
7.1.8 Test/Trouble shoot The Serial Output .....	Page 7-1
<b>7.2 SIMULATING A WEIGHMENT .....</b>	<b>Page 7-1</b>
<b>7.3 TEST/TROUBLESHOOT THE INTERNAL MODEM .....</b>	<b>Page 7-1</b>

<b>SECTION VIII Security System</b> .....	<b>Page 8-1</b>
<b>8.1 INTRODUCTION</b> .....	<b>Page 8-1</b>
8.1.1 Lock On/Off .....	Page 8-1
8.1.2 Menu Locks .....	Page 8-1
8.1.3 Key Locks .....	Page 8-1
<b>8.2 PASSWORD ACCESS</b> .....	<b>Page 8-1</b>
8.2.1 Selecting/Storing A Password .....	Page 8-1
8.2.2 Entering The Password .....	Page 8-1
<b>SECTION IX Operation</b> .....	<b>Page 9-1</b>
<b>9.1 GENERAL</b> .....	<b>Page 9-1</b>
<b>9.2 GROSS WEIGHT WEIGHING</b> .....	<b>Page 9-1</b>
<b>9.3 ZERO OPERATION</b> .....	<b>Page 9-1</b>
<b>9.4 NET WEIGHT WEIGHING</b> .....	<b>Page 9-1</b>
<b>9.5 TARE OPERATION</b> .....	<b>Page 9-1</b>
<b>9.6 ERROR DETECTION AND CORRECTION</b> .....	<b>Page 9-1</b>
<b>SECTION X Protocol, and Modem Options</b> .....	<b>Page 10-1</b>
<b>10.1 GENERAL</b> .....	<b>Page 10-1</b>
<b>10.2 THE SERVICE LINK MODEM</b> .....	<b>Page 10-1</b>
<b>10.3 MODBUS RTU PROTOCOL</b> .....	<b>Page 10-1</b>
10.3.1 Common Data Format .....	Page 10-1
10.3.2 Modbus RTU Functions Supported .....	Page 10-1
10.3.3 Setup .....	Page 10-1
<b>10.4 MODBUS PLUS INTERFACE</b> .....	<b>Page 10-1</b>
10.4.1 Routing Path Addressing .....	Page 10-1
10.4.2 Global Data Transfers .....	Page 10-2
10.4.3 Wiring and Node Addressing .....	Page 10-2
10.4.4 Configuration .....	Page 10-2
10.4.5 Data Formatting .....	Page 10-2
10.4.5.1 Double Precision Format .....	Page 10-2
10.4.5.2 Vishay BLH Data Format .....	Page 10-3
10.4.6 Flashing LED Status .....	Page 10-3
10.4.7 Manipulating The Front Panel Display .....	Page 10-3
<b>10.5 PROVOX PROTOCOL</b> .....	<b>Page 10-4</b>
10.5.1 Wiring .....	Page 10-4
10.5.2 Configuration .....	Page 10-4
10.5.3 Operation .....	Page 10-4

<b>SECTION XI Profibus .....</b>	<b>Page 11-1</b>
<b>11.1 THE INTERFACE DEFINED .....</b>	<b>Page 11-1</b>
11.1.1 Profibus DP .....	Page 11-1
11.1.2 GSD Files .....	Page 11-1
<b>11.2 INTERFACE WIRING .....</b>	<b>Page 11-1</b>
<b>11.3 LCp-100 MENU CHANGES .....</b>	<b>Page 11-1</b>
11.3.1 I/O Menu Changes .....	Page 11-2
11.3.2 Diagnostic Menu Changes .....	Page 11-3
11.3.3 Display Menu Changes .....	Page 11-4
<b>11.4 DATA EXCHANGE FORMATS .....</b>	<b>Page 11-5</b>
11.4.1 Input Data (LCp-100 Transmission) .....	Page 11-5
11.4.2 Output Data (from the Master) .....	Page 11-5

Trademark Usage Acknowledgments

Allen-Bradley is a trademark of Allen-Bradley Company, Inc. PLC and PLC-5 are trademarks of Allen-Bradley Company, Inc.  
Modbus is a trademark of AEG Schneider Automation.  
Provox is a trademark of the Fisher Rosemount Co.  
Profibus is a trademark of Siemens AG

# SECTION I

## General Information

### 1.1 Instrument Description

The LCp-100 'Expert Series' indicator/transmitter (Figure 1-1) is a microprocessor based device designed to convert the mV/V signal from strain gage type force transducers (load cells) into a high resolution digital signal representing force or weight. Units operate at either 115 or 230 Vac and provide a regulated, fault protected 10 Vdc excitation for up to eight 350 ohm transducers. Standard features include an RS-422/485 serial port with PC interface or simplex output ASCII protocol (Digi-System Network available in 1996), a sigma delta type A/D converter and dynamic digital filtering. Options include a sixteen bit resolution analog output, the Allen Bradley Remote I/O interface, various serial protocol options such as MODBUS, and an internal modem for remote configuration, service and monitoring.

CE Marked LCp-100 instruments have passed both the EU (European Union) Low Voltage and EMC Directives. Although a European Standard, CE Marked units meet and may even exceed US conventional performance standards.

Each unit is housed in an aluminum case with a powder coated aluminum panel mounting bezel. NEMA 4, 4X or explosion-proof wall mount enclosures are available as options. Simple entry of calibration data, diagnostic parameters, and filter selections is accomplished using the front panel keypad. All electrical connections are made at the rear panel with unpluggable screw terminal connectors.

#### 1.1.1 Introducing the Plug-n-Weigh Concept

The Vishay BLH Plug-n-Weigh concept takes advantage of technology to minimize start-up time and the operator learning curve. Intuitive configuration menus, self configuration of many set-up parameters, and simple push-button type digital calibration combine together to make the LCp-100 one of the easiest process instruments to configure and operate.




Figure 1-1. The LCp-100

#### 1.1.2 The Safe-Weigh Software System

Safe-Weigh software system benefits include Expert System Diagnostics, Dynamic Digital Filtering, and a wide range of proven DCS/PLC connectivity options. Expert System Diagnostics provides on-line preventative maintenance information which quickly identifies electrical and/or mechanical problems. Dynamic Digital Filtering ensures precise, repeatable set point control in 'noisy' process environments. Proven connectivity with Allen-Bradley, Modicon (AEG Schneider) General Electric, Johnson Yokogawa, Honeywell, Fisher-ProVox, Bailey, and other PLC/DCS devices eliminates the risks associated with digital integration of weight information into the process control environment.

#### 1.1.3 The LCp-100 Front Panel

All configuration, calibration, and operation transactions are performed using the front panel push buttons and the high intensity vacuum fluorescent display (Figure 1-2). The user friendly design separates the operating push buttons (gross/net, zero, tare and print) from the configuration menu keypad. The two line alphanumeric display indicates weight data and status while in the operate mode and provides instructions etc. during the configuration mode.




Figure 1-2. The LCp-100 Front Panel




Figure 1-3. Main Flow Diagram

# LcP-100 Overall Flow Diagram

#### 1.1.4 Main Configuration Flow Diagram

LCp-100 configuration is performed using the menu driven keypad on the right side of the front panel and follows the flow diagram presented in Figure 1-3. This diagram shows the overall structure and general guidelines of the LCp-100 set-up, calibration, filter, display, I/O, diagnostic, and security configuration routines. Detailed explanations of sub menu parameter selections are defined in sequential chapters, starting with Section III. To browse through the menus, press MENU and use the arrow keys to move across menu subjects, or up and down within a menu. Parameters are not actually changed until the edit and enter keys are used.

#### 1.1.5 Serial Communication

The standard LCp-100 is equipped with a single serial communication port that can be selected to operate as an RS 422 full duplex, or RS 485 half duplex port. The type selection is made using a series of DIP switches on the back panel. Protocol selection is made within the keypad menu structure. The standard version is provided with Vishay BLH network or ASCII protocol selections. This network protocol (avail. 1996) allows the LCp-100 to communicate in a local area network to a Vishay BLH network controller/gateway. The ASCII protocol option is designed to communicate with a printer, PC, remote display, or data logger and can be selected for continuous or demand operation. Extensive diagnostics verify transmit and receive, proper parity and framing, and a visualization function allows the user to view the actual serial transmit and receive characters. See Section II for wiring information and Section VI for protocol information.

## 1.2 OPTIONS

LCp-100 units are available with several different application enhancement options. Options include various mounting enclosures, custom network interfaces and protocols, and a factory-link modem for on-line service/calibration assistance. All options will be fully defined later in this manual.

#### 1.2.1 Mounting Options

For units located in a general factory/plant floor, or if corrosive, hose down, or sanitary requirements are a factor, a NEMA 4X stainless steel enclosure is available. For Div. 2 hazardous locations, units are available with FM approval as a non-incendive device. For Division 1 hazardous locations an explosion proof enclosure is available. (Note: Vishay BLH Intrinsic Safety Barrier Sets must be specified when load cells are located in a Division I area.)

#### 1.2.2 Internal Summing Junction Board (Optional)

For systems where the LCp-100 is located within 10 meters of the load cells, an optional 306 summing board is available mounted inside the NEMA 4/4X enclosure.

#### 1.2.3 Analog Output

Optionally the LCp-100 is available equipped with a high resolution 16 bit analog output. This output can be configured for 4-20 mA, 0-20 mA, or 0-24 mA operation via rear panel DIP switch selections. Set-up and calibration of the analog output is configured via the menu keypad and can be configured to track gross or net weight data. Loop diagnostics are also provided to verify that the analog connection is in fact. See Section II for wiring information and Section VI for configuration details.

#### 1.2.4 Allen-Bradley Remote I/O Network Interface

The Allen-Bradley Remote I/O interface is a communication link that supports remote, time critical I/O control communications between a master processor and a remote I/O slave. It is typically used to transfer I/O bit images between the master and slave. The LCp-100 represents a quarter (1/4) Rack of discrete I/O with 32 bits of input and output image files to the scanning PLC. All weight data and status information uses discrete reads and writes to communicate scale information to the PLC in the shortest time possible. Block data transfers are used to communicate non-time critical diagnostic and calibration data, and remotely configure diagnostic limits and digital filter parameters.

#### 1.2.5 MODBUS RTU Protocol

MODBUS is often recognized as an industry standard method of digital communication protocol between a master or host computer and a slave device. This protocol was originally developed by Modicon to communicate discrete and analog information between a PLC and a master host. As implemented in the LCp-100, this protocol efficiently communicates weight and diagnostics information to a MODBUS Master driver equipped host.

### 1.2.6 Fisher Provox Protocol

This option allows direct communication with a Fisher CL6921 type interface card when the CL6921 is configured for 'Toledo' interface. Weight data is transmitted every 50 msec from the standard LCp-100 serial output port.

### 1.2.7 MODBUS Plus Protocol

MODBUS Plus protocol allows the LCp-100 to communicate on a peer-to-peer network link with Modicon 984 and Quantum PLC devices. See Section X for a full description of this interface.

## 1.3 LCp-100 Specifications

### Performance

Resolution	1048576 total counts
Displayed Resolution	700,000 counts
Conversion Speed	50 msec
Displayed Sensitivity	0.05 $\mu$ V per count
Noise	0.4 $\mu$ V per count (min. filt. setting)
Full Scale Range	3.5 mV/V
Dead Load Range	100% full scale
Input Impedance	10 m-ohms min
Excitation Voltage	10 Vdc @ 250 mA
Linearity	(0.0015% full scale one conversion
Software Filter	multi-variable up to 10,000 msec
Step Response	one conversion
Temp Coefficient Zero	(2ppm/ $^{\circ}$ C
Temp Coefficient Span	(7ppm/ $^{\circ}$ C

### Environment

Operating Temperature	-10 to 55 $^{\circ}$ C (15 to 131 $^{\circ}$ F)
Storage Temperature	-20 to 85 $^{\circ}$ C (-5 to 185 $^{\circ}$ F)
Humidity	5 to 90% rh non-condensing
Voltage	117/230 Vac (15% @ 50/60 Hz
Power	15 watts max

### Enclosure

Dimensions (std)	4.63 x 8.40 x 6.5 in. HWD
NEMA 4/4X, 12 (opt)	8.5 x 13.5 x 10.45 in. HWD

### Display

Type	high intensity cobalt green vacuum fluorescent
Active Digits	7 digit alpha numeric .59" high for weight; 8 digit alpha numeric .39" high for status

### Materials

Aluminum Case & Bezel	overlay meets 94V-0 rating
-----------------------	----------------------------

### Analog Output (Optional)

Conversion	16 bit D-A
Current Selectable max.	4-20 mA or 0-20 mA - 600 ohm max. 0-24 mA - 500 ohm max.

### Remote Digital Inputs (Optically Isolated)

(Contact closure or dc logic compatible)	
Closed (Momentary)	logic low
Open	logic high
Cable Length	100 feet max.

### Communications (Standard)

Serial RS-422/485	full or half duplex ASCII, printer, Provox, or MODBUS protocols odd, even or no parity- selectable
Baud Rates	300, 1200, 2400, 4800, 9600, or 19200
Addressing	0-99

### Approvals/CE Marking

FM (Factory Mutual)	3611
CSA	C22.2 (all applicable sections)
IEC 801-2	ESD susceptibility, category B
IEC 801-3	radiated electromagnetic field, cat. A
IEC 801-4	conducted line transients, cat. B
EMI Emissions	FCC part 15 subpart B, Class A Canadian Dept. of Communication, Class A
EN 5501	Group 1, Class A
IEC 1010-1/EN61010-1	Electrical Safety
EN50082-1 1992	Susceptibility: subparts 801,2,3 & 4
EN55011	Emissions: Equipment Class I, Group A

### Special Interfaces (Optional)

Allen-Bradley	Remote I/O - 1/4 Logical Rack
Modbus RTU	slave
Modbus Plus	supports global data
Profibus	slave

### Internal Service Modem (Optional)

Baud Rate	2400; Bell 212 and 103 compatible
Availability	U.S.A. and Canada only

## 1.4 ORDERING INFORMATION

### Basic Unit LCp-100 [M]-[AP]-[C]-[B]

[M] Mounting	(1) NEMA 4X Panel Mount (2) #1 & FM/CSA Division 2 Approval (5) NEMA 4x Stainless Steel Wall Mount (6) #5 & CSA Division 2 Approval (7) #5 with 306 Internal Summing Board (8) #6 with 306 Internal Summing Board (13) #6 with type Y purgesuitable for Div. 1 areas (15) NEMA 4/7/9 Ex Enclosure (Class I, II, III; Div. 1, Groups B-G)
[A] Expansion Slot A	(1) None (3) MODBUS Plus (4) Allen-Bradley Remote I/O (5) Profibus DP (not FM approved) (6) DeviceNet (CSA Approval Pending)
[P] Process Inputs and Outputs	(1) Remote Function Inputs (2) #1 & Analog Current Output (9) #2 With 120 Updates/Sec, Bi-Polar NOTE: Available with A1 and A5 Options Only
[C] Communication	(1) RS-485 or RS-422 or Multi-Drop RS-422 W/PC Interface, ASCII Protocol (2) #1 & MODBUS RTU Protocol (3) #1 & Provox Protocol (includes 20 mA serial converter board)
[B] Expansion Slot B	(1) None

## 1.5 WARRANTY POLICY

Vishay BLH warrants the products covered hereby to be free from defects in material and workmanship. Vishay BLH's liability under this guarantee shall be limited to repairing or furnishing parts to replace, f.o.b. point of manufacture, any parts which, within one (1) year from date of shipment of said product(s) from Vishay BLH's plant, fail because of defective workmanship or material performed or furnished by Vishay BLH. As a condition hereof, such defects must be brought to Vishay BLH's attention for verification when first discovered, and the material or parts alleged to be defective shall be returned to Vishay BLH if requested. Vishay BLH shall not be liable for transportation or installation charges, for expenses of Buyer for repairs or replacements or for any damages from delay or loss of use for other indirect or consequential damages of any kind. Vishay BLH may use improved designs of the parts to be replaced. This guarantee shall not apply to any material which shall have been repaired or altered outside of Vishay BLH's plant in any way, so as in Vishay BLH's judgment, to affect its strength, performance, or reliability, or to any defect due in any part to misuse, negligence, accident or any cause other than normal and reasonable use, nor shall it apply beyond their normal span of life to any materials whose normal span of life is shorter than the applicable period stated herein. In consideration of the forgoing guarantees, all im-

plied warranties are waived by the Buyer, Vishay BLH does not guarantee quality of material or parts specified or furnished by Buyer, or by other parties designated by buyer, if not manufactured by Vishay BLH. If any modifications or repairs are made to this equipment without prior factory approval, the above warranty can become null and void.

## 1.6 FIELD ENGINEERING

Authorized Vishay BLH Field Service Engineers are available around the world to install LCp-100 transmitters and/or train factory personnel to do so. The field service department at Vishay BLH is the most important tool to assure the best performance from your application. Field service phone numbers are listed below.

Factory: (Main Number) (781) 821-2000 ex.216

Midwest: (815) 879-8818

Southwest (281) 655-5041

Canada: (416) 251-2690 or (800) 567-6098 in Canada



# SECTION II Installation

## 2-1. INTRODUCTION

This chapter provides LCp-100 mounting and electrical installation information. Instruments will operate accurately (to specification) in locations with temperatures ranging from -10°C to +55°C (+14°F to +130°F). The installation location should be free of vibration. Unless equipped with the proper enclosure option, instruments should not be located in areas containing explosive or corrosive vapors. In all installations, ac (mains) power should be supplied from a clean (transient free) instrument power source.

## 2-2. MOUNTING

### 2.2.1 Standard Unit Mounting

Standard LCp-100 controllers are shipped with the necessary hardware for panel mounting. Outline and panel cutout dimensions are depicted in Figure 2-1. Installation of panel mount adapters is shown in Figure 2-2 (following page).

### 2.2.2 Optional NEMA 4/4X Enclosures

NEMA 4 and 4X enclosures are equipped with four pre-punched holes for mounting to a wall or bracket. A U-bolt can be used for mounting to a pipe support. The enclosure should be installed in a vibration free environment close to the load cell summing junction box. If conduit is used to shield interconnecting cables, drains should be provided to reduce the possibility of condensate entering the enclosure. Outline dimensions for NEMA 4/4X enclosures are presented in Figure 2-3 (following page).

NOTE: Units purchased with the NEMA enclosure option can be equipped with an internal transducer summing board (see paragraph 2.3.9).




Figure 2-1. Standard Unit Outline Dimensions




Figure 2-2. Panel Mounting Arrangement




Figure 2-3. NEMA 4/4X Outline Dimensions




Figure 2-4. The LCP-100 Rear Panel

## 2.3 ELECTRICAL CONNECTIONS

### 2.3.1 The LCP-100 Rear Panel

Figure 2-4 shows the LCP-100 rear panel. Call outs depict wiring locations for all electrical connections. NOTE: See Appendix A for all electrical wiring diagrams on a single page.

### 2.3.2 Transducer Signal Inputs

Transducer input leads are wired to the LCP rear panel terminal block shown in Figure 2-5. Vishay BLH load cells and junction box cables are shipped with pre-stripped, tinned leads so that leads need only be inserted in the proper terminal location and the screw above tightened securely. Lead designations are clearly labeled for standard six conductor input cables (usually coming from a junction box). When using Vishay BLH supplied junction boxes, refer to docu-

ment IS 308A-1 INSTALLATION AND OPERATING INSTRUCTIONS, for cable designations and lead color coding. For applications which use a four conductor cable (usually coming from a single load cell), jumpers must be installed from SEN + to EX + and SEN - to EX -. To insure good electrical and mechanical connection, Vishay BLH recommends that jumper leads be soldered to load cell leads.

**NOTE:** For many load cells, excitation (EX) leads are referred to as INPUT, and signal leads (SIG) are referred to as OUTPUT.

**NOTE:** If tension load cells are used, red (-signal) and white (+signal) leads may need to be reversed.

### 2.3.3 Mains (ac) Power

LCP-100 instruments are shipped ready to operate at 115 Vac (50 or 60 Hz). For 220 Vac operation, remove the rear panel and change the internal voltage selection switch as shown in Figure 2-6.




Figure 2-5. Load Cell Connections




Figure 2-6. Vac Power Selection





Figure 2-7. AC Voltage Connections

Each instrument is protected with a 1/4 amp, 250 volt 'T' type fuse located adjacent to the ac power socket. If the fuse opens, replace it with the same type, current, and voltage rating.

### 2.3.4 Serial Communication

A 4-socket mating half connector is provided for serial communication wiring. Connect wires for either RS-485 or RS-422 operation as shown in Figure 2-8. Note that connector position 5 is a ground terminal and should be used for three-wire, RS-485 communication networks. Set DIP switch S1 positions 1-4 for desired interface function (Figure 2-8). See Section VI for details concerning serial interfacing.



RS 422/ 485 COMMUNICATION			
PIN NO	SIGNAL NAME	SIGNAL	
		RS 422	RS 485
1	TxD+	TRANSMIT DATA +	NOT USED
2	TxD-	TRANSMIT DATA -	NOT USED
3	RxD+	RECEIVE DATA +	DATA +
4	RxD-	RECEIVE DATA -	DATA -

DIP SWITCH SETUP				
	SW1.1	SW1.2	SW1.3	SW1.4
RS 422 MULTIDROP	ON	OFF	OFF	OFF
RS 422 FULL DUPLEX	OFF	OFF	OFF	OFF
RS 485 HALF DUPLEX	ON	ON	ON	ON

**TERMINATION RESISTOR**

DIP SWITCH #5 IN ON POSITION CONNECTS AN INTERNAL 120 OHM RESISTOR ACROSS THE RxD+ AND RxD- SIGNALS

Figure 2-8. Serial Communication Configuration

### 2.3.5 Analog Output (Option)

Analog current output is optional on LCP-100 instruments. To select current output type; 4-20 mA, 0-20 mA, or 0-24 mA, set rear panel DIP switch positions 7 and 8 as shown in Figure 2-9. Use the two-socket mating half terminal connector to attach plus and minus signal wires as shown in Figure 2-9. Route wires away from ac power lines and other EMI sources to prevent interference. Section VI provides analog output configuration procedures.




Figure 2-9. Analog Current Selection/Connection

### 2.3.6 Digital (Remote) Inputs

Certain front panel key functions can be initiated remotely using the rear panel digital inputs. Figure 2-10 gives wiring designations for remote operation of the ZERO, TARE, Gross/Net (GN), and PRINT keys. Interconnecting wire/cable length should not exceed 50 feet. Route wires/cable away from ac power lines and other EMI sources to prevent interference.




Figure 2-10. Remote Digital Inputs

### 2.3.7 Allen Bradley Remote I/O (Optional)

Units ordered with the Allen-Bradley remote I/O option have a 3-socket mating half connector for the REMOTE I/O port. Wiring designations are presented in Figure 2-11. Technical manual TM020 presents a complete description of the Allen-Bradley interface.




Figure 2-11. Allen-Bradley Remote I/O Option

### 2.3.8 Summing Junction Box Considerations

Vishay BLH recommends using the Model 306 (not supplied) transducer summing junction box with the LCP-100. If the Vishay BLH Model 308A junction box is used, resistors R1 and R2 must be removed to ensure proper operation (see Figure 2-12).




Figure 2-12. 308A Junction Box Modification

### 2.3.9 Internal 306 Junction Board (Optional)

Units shipped in the optional NEMA 4/4X enclosure may be ordered with an internal summing junction board as shown in Figure 2-3 (NEMA 4/4x outline dimensions). If the 306 option board is installed, transducers connect directly to the junction board, within the enclosure, eliminating the need for an external junction box. Connect transducers as shown in Figure 2-13. Wiring between the 306 board and the LCP-100 transducer input is performed and tested at the factory.




Figure 2-13. 308A Junction Board Transducer Connections

### 2.3.10 Modbus Plus

Units shipped with the Modbus Plus option have a custom rear panel with a specific 9-socket, D-type Modbus Plus Connector (see Figures 2-14, 10-2, and paragraph 10.4.1). This connector mates with an ASA Modicon AS-MBKT-085 9-pin, D-type connector\*. Vishay BLH recommends using ASA Modicon number 490NAA27101\* shielded cable for interconnect wiring.

Instructions for assembling an AS-MBKT-085 based connector cable are located in the 'MODBUS PLUS Network Planning and Installation Guide' (#GM-MBPL-001) available from the AEG Schneider Corporation.

\* not supplied by Vishay BLH




Figure 2-14. 9-Socket Modbus Plus Connector

# SECTION III

## Set-Up and Calibration

### 3.1 INTRODUCTION

After installation, set-up and calibration is the next step in preparing the the LCp-100 for operation (see main menu diagram, Figure 1-3). Setup and calibration is accomplished easily using the front panel display and eight configuration keys. Figure 3-1 (page 3-2) presents details for set-up parameter entry and Figure 3-2 (page 3-3) shows procedures for each calibration type.

### 3.2 SET-UP SYSTEM PARAMETERS

Set-up establishes scale operating parameters such as system capacity, decimal point location, display units, count by, etc. Follow the flow diagram presented in Figure 3-1 to enter or alter set-up parameters.

#### 3.2.1 Display Units

Designate the desired display units as pounds, kilograms, tons, ounces, grams, newtons, kilonewtons, liters, or blank (no units). Selection also appears on print outs and other serial transactions.

#### 3.2.2 Capacity

Enter the full scale system capacity value. (capacity is the rated load of the load cell(s) or platform - not simply live load or gross weight.) A capacity of 10000 can be displayed as 0.010000, 0.10000, 1.0000, 10.000, 100.00, 1000.0, or 10000. depending upon decimal point location.

#### 3.2.3 Decimal Point Location

Position the decimal point as desired for weight display and serial communication.

#### 3.2.4 Output

Enter the rated mV/V output of the system. (The electrical output at rated capacity independent of excitation) The rated output of multi-cell system is the average of the rated output of all the cells. For example: In a three cell system with load cell rated outputs of 2.01, 2.05, and 1.95 mV/V, the average rated output is 2.003 mV/V.

#### 3.2.5 Front Panel Display Counts

Define the count value of each display increment by selecting 1, 2, 5, 10, 20, 50, or 100 (note that decimal selection still applies). The LCp-100 will automatically default to the best possible resolution.

### 3.3 SYSTEM CALIBRATION

The LCp-100 offers three types of calibration; quick, deadload, and keypad. Both quick and keypad calibration use an internal mV/V reference within the LCp-100 to perform an electrical only type calibration. The deadload type calibration is a method that is used when known amounts of weight are applied to the vessel or scale to achieve calibration. Figure 3-2 provides flow diagrams for each calibration type.

For a more detailed discussion of the most appropriate calibration method refer to Vishay BLH Pub. FSD 001, 'An Overview of Calibration Methods and Procedures for Process and Inventory Weigh Systems'.

#### 3.3.1 Quick Type Calibration

Quick calibration is the fastest and least complex method of calibration. Based upon entries of scale capacity and mV/V output, the LCp-100 will automatically establish a calibration. This method is generally suitable on any linear system that has minimal piping or other load shunting structures.

#### 3.3.2 Deadload Calibration

Deadload calibration is potentially the most complex method but results in the highest system accuracy. Deadload calibration requires that known quantities of weight be added incrementally to the scale/vessel, preferably to full capacity. This method is preferred on systems that have attached pipes or other load shunting structures.

#### 3.3.3 Keypad Calibration

The LCp-100 is factory calibrated as a very precise mV/V measurement device. The keypad calibration method establishes a relationship between force and mV/V, resulting in a very accurate electrical type of calibration. Keypad calibration requires a calibration sheet (Figure 3-3, page 3-4) for each weigh system load cell. The cal. sheet presents the load cell mV/V output reading for either 3 or 10 known weight/force values. Sheets also include a zero balance (no load) mV/V reading. The keypad calibration method allows for the entry for the keypad entry of up to 10 points. On multi-cell systems, each point is an average of all the load cells at that specific capacity. This method is applicable on systems with minimal piping or other load shunting structures and can be used to correct for load cell non-linearities.

# Enter/Alter Set-Up Parameters

Choose Display/Printout Unit Type

Enter Full Scale Capacity

Locate Display/Printout Decimal Point

Enter Scale Output

Rated m/V output of system

SELECTIONS:  
 12,5,10,20,  
 50, or 100

SELECTIONS:  
 LB (pounds)  
 KG (kilograms)  
 TN (tons)  
 OZ (ounces)  
 GM (grams)  
 N (newtons)  
 KN (kilonewtons)  
 L (liters)  
 (blank space)

SELECTIONS:  
 0 to  
 9999999

SELECTIONS:  
 Use EDIT,  
 ▼, and then  
 ENTER

## General Key Functions:

- Step back to previous menu selection.
- Advance to next menu selection.
- Advance to next main menu selection.
- Return to live operation from menu.
- Change sub menu parameters.
- Store displayed sub menu parameter in memory.



## To Enter/Alter a Numeric Value:


- Press to initiate a change.
- Press to increment selected digit.
- Press to decrement selected digit.
- Press to advance to next digit.
- Press to return to previous digit.
- Press to store selection in memory.

## To Enter/Alter a Parameter Selection:

- Press to initiate a change.
- Press to view parameter options.
- Press to store selection in memory.

Figure 3-1. Set-Up Parameter Entry

# Calibration Type - Flow Diagrams



## General Key Functions:

- ▲ Step back to previous menu selection.
- ▼ Advance to next menu selection.
- [MENU] Advance to next main menu selection.
- [ESC] Return to live operation from menu.
- [EDIT] Change sub menu parameters.
- [ENTER] Store displayed sub menu parameter in memory.



## To Enter/Alter a Numeric Value:

- [EDIT] Press to initiate a change.
- ▲ Press to increment selected digit.
- ▼ Press to decrement selected digit.
- ▶ Press to advance to next digit.
- ◀ Press to return to previous digit.
- [ENTER] Press to store selection in memory.

## To Enter/Alter a Parameter Selection:

- [EDIT] Press to initiate a change.
- ▼ Press to view parameter options.
- [ENTER] Press to store selection in memory.

Figure 3-2. Calibration Types & Parameters



# Calibration Chart

Customer: ABC Co. P.O: 28523004D

Capacity 50000 lb Type C2P1 Serial No. 71258

Mode Tension Bridge A Test Report No. C37-8500

Indicator N.A. Serial No. N.A.

Date Of Calibration 4/45/98 Temperature: 70 F

Calibrated By: M. Houston Humidity: 58 %

Applied Load lbf	Response		
	Run 1 mv/V	Run 2 mv/V	Run 3 mv/V
0	0.0000	0.0000	0.0000
5,000	0.2000	0.2000	0.2000
10,000	0.4001	0.4001	0.4001
15,000	0.6001	0.6001	0.6001
20,000	0.8002	0.8002	0.8002
25,000	1.0003	1.0003	1.0003
30,000	1.2003	1.2003	1.2003
35,000	1.4003	1.4003	1.4003
40,000	1.6003	1.6003	1.6003
45,000	1.8003	1.8003	1.8003
50,000	2.0003	2.0003	2.0003
25,000	1.0000	1.0000	1.0000
0	0.0000	0.0000	0.0000

Applied Load [lb]	Output Average lb	Ideal Output lb	Output Error lb	Output Error % FS	Hysteresis Error % FS
0	0.0000	0.0000	0.0000	.000%	
5,000	0.2000	0.2000	0.0000	-.001%	
10,000	0.4001	0.4001	0.0000	.002%	
15,000	0.6001	0.6001	0.0000	.000%	
20,000	0.8002	0.8001	0.0001	.004%	
25,000	1.0003	1.0002	0.0001	.007%	
30,000	1.2003	1.2002	0.0001	.006%	
35,000	1.4003	1.4002	0.0001	.004%	
40,000	1.6003	1.6002	0.0001	.003%	
45,000	1.8003	1.8003	0.0000	.001%	
50,000	2.0003	2.0003	0.0000	.000%	
25,000	1.0000	1.0002	-0.0002	-.007%	-.015%
0	0.0000	0.0000	0.0000	.000%	.000%


  
 Q. C. Manager 4/21/98

Figure 3-3. Sample Load Cell Calibration Certificate

# SECTION IV

## Dynamic Digital Filter

### 4.1 GENERAL

The LCp-100 uses a two stage digital filter. Each stage requires parameter entries as shown in Figure 4-1 (next page). Make parameter entries while viewing live weight value on the front panel display.

#### 4.1.1 Digital Averaging

The filter first stage calculates a running average of weight input readings. Available selections are 1, 2, 4, 8, 16, 32, 64, and 128 conversions (see Figure 4-1). Using a 'first in - first out' algorithm, running averaging provides display updates every 50 msec regardless of the number of readings averaged. However, since each conversion averaged adds 50 msec to the filter length, the larger the averaging selection, the longer the filter length becomes. Table 4-1 shows the time relationship between conversions averaged and filter length.

#### 4.1.2 Band Selection

The second stage of the filter, BAND, is applied after averaging is selected. A BAND value between 0 and 100 must be entered as shown in Figure 4-1. Dynamic Digital Filtering constantly compares the amount of input signal change between consecutive conversions. If the difference falls within the BAND setting, a mathematical filter attenuates the conversion to conversion variation. Once the difference between conversions exceeds the BAND selection, the BAND filter is canceled and the display tracks live weight with maximum response. To achieve the best overall filter response, keep the BAND selection as low as possible without hindering system performance (see next paragraph for set-up instructions). If the BAND setting is higher than necessary, sensitivity to small weight changes will be reduced.

#### 4.1.3 Filter Set-Up Procedures

Setting filter parameters requires a balance between achieving maximum noise reduction and maintaining quick response and good sensitivity to real weight changes. The goal of filter set-up is to use the lowest averaging and BAND selections needed for smooth system display/operation. If selections are higher than necessary, accurate detection of small weight changes may be hindered. Using the six steps presented in Table 4-2, tune the system to its maximum performance level.


Table 4-1. Averaging Selections and Filter Length

Average	Response
1	0.05 sec
2	0.10 sec
4	0.20 sec
8	0.40 sec
16	0.80 sec
32	1.60 sec
64	3.20 sec
128	6.40 sec

Table 4-2. Dynamic Digital Filter Set-Up Procedures

- 1.) Begin with the BAND set at a low value (approx. 4-10).
- 2.) Increase averaging until the noise (watch display) is reduced to the least significant digit (approx. +/- 10 divisions).
- 3.) Increase BAND, if necessary, to reduce the remaining noise to the desired level.
- 4.) If increasing the BAND value does not reduce the noise, return to averaging and select the next higher setting, then repeat step three.
- 5.) If the BAND value required to quiet the display becomes large (65-100), it may be better to use more averaging. Try to achieve the best balance between BAND (small weight change sensitivity reduction) and averaging (longer response time).
- 6.) If a stable weight display cannot be achieved with reasonable selections, it may be necessary to change the instrument set-up to reduce sensitivity.

# Enter/Alter Filter Parameters



## General Key Functions:

- Step back to previous menu selection.
- Advance to next menu selection.
- Advance to next main menu selection.
- Return to live operation from menu.
- Change sub menu parameters.
- Store displayed sub menu parameter in memory.



## To Enter/Alter a Parameter Selection:

- Press to initiate a change.
- Press to view parameter options.
- Press to store selection in memory.

Figure 4-1. Dynamic Digital Filter Parameter Entry

# SECTION V

## Front Panel Display Functions

### 5.1 FRONT PANEL FUNCTIONS

The front panel display of the LCp-100 (Figure 5-1) includes a two line alpha numeric digital display for weight and status information as well as horizontal and vertical bar graphs and diagnostic alarm annunciators. The bar graphs and alarm annunciators can be configured to display various information. Use the display menu flow diagram (Figure 5-2) to configure the front panel functions for desired system operation.

#### 5.1.1 Horizontal Bar Graph

The horizontal bar graph is considered the primary level indicator and is typically used to monitor the overall gross weight contents of the scale vessel. Vacuum fluorescent segments located under the 0 to 100% bar graph give instant visual reference to system capacity. Select ON to use; OFF for no function. Choose net or gross weight tracking and then enter the starting and ending weight values. Note that this indicator also can be configured for reverse polarity depending upon the starting and ending values.

#### 5.1.2 Vertical Bar Graph

The vertical bar graph is considered the secondary level indicator and is typically used to monitor net weight. Located to the right of the weight display area, this indicator provides a graphical representation of 0 to 100% in 10% increments (each arrow = 10% capacity). Select ON to use; OFF for no function. Choose net or gross weight tracking and then enter the starting and ending weight values. Note that this indicator also can be configured for reverse

polarity depending upon the starting and ending values.

#### 5.1.3 Alarm Status Annunciators

Eight front panel alarm/status annunciators provide ongoing system diagnostic information. Each annunciator can be configured to represent 1 of 11 conditions; OFF (no function), system in motion, zero limit exceeded, overload limit exceeded, serial communication receive, serial communication transmit, serial communication parity error, serial framing error, analog output fault, analog output over high selection, analog output under low selection, Allen-Bradley Remote I/O (option) status, modem receive active, modem transmit active, or Modbus Plus status. Once configured as A1-A8, vacuum fluorescent segments will be illuminated when configured condition is true. Configure each annunciator consecutively as shown in Figure 5-2.

#### 5.1.4 Configuring The TARE Key

The front panel TARE key can be configured for manual or automatic operation. If 'automatic' is selected and the unit is operating in net mode, the displayed weight value will be zeroed resulting in a display of zero (units) net. If manual is selected and the unit is operating in net mode, the operator will be prompted to enter the desired tare weight value. TARE has no function in the gross weight weighing mode.




Figure 5-1. The LCp-100 Functional Front Panel

# Display Menu Flow Diagram




Figure 5-2. Front Panel Functions, Configuration Menu

### 5.1.5 Configuring The ZERO Key

The front panel ZERO key can be configured for manual or automatic operation. If 'automatic' is selected, the displayed gross weight value will be zeroed out when the key is pressed. If manual is selected, the operator will be prompted to enter the desired gross zero weight value. ZERO has no function in the net weight weighing mode.

A full scale limit selection also must be entered for the zero key. Enter a zero limit value between scale zero and full scale capacity (recommended 2-20%). The zero key will not function automatically or manually after the displayed weight value has exceeded the zero limit entry.

### 5.2 VIEW mV/V SIGNAL

Pressing the right arrow configuration key during live operation results in a display of the current mV/V input signal. This function is useful for diagnosing electrical drift/malfunction errors. Recording mV/V signals during calibration procedures provides check-cal or re-calibration test points.

Pressing the left arrow configuration key during live operation results in a display of the current live mV/V input signal (dead weight signal subtracted).



# SECTION VI

## Analog Output and Serial Communication

### 6.1 ANALOG OUTPUT CONFIGURATION (Optional)

#### 6.1.1 Output Definition

LCp-100 indicators provide a high resolution analog current output, representing either gross or net weight, for driving external process equipment/recorders. Use rear panel switch 1 positions 7 and 8 (Figure 2-8) to select either 4-20, 0-20, or 0-24 mA operation (note load resistance reduction with 0-24 mA). This output is based upon a 16 bit digital to analog (D-A) conversion which represents up to one part in 65536 of analog precision. The scaling of the output is accomplished after the LCp-100 is calibrated and can be ranged for any portion of the gross or net weight output curve.

Systems using the analog output for level control usually configure the output to track gross weight (live product weight). Batch control systems that use weight as a variable to determine set point cutoffs can be configured to operate in the net weighing mode while using a discrete remote input to activate the tare function.

#### 6.1.2 Set-Up Procedure

Connect a current meter to the rear panel analog output points (see Figure 2-8 for +, - designations) and proceed with ANALOG I/O configuration as shown in Figure 6-1 (page 6-2).

### 6.2 SERIAL COMMUNICATION

LCp-100 units come with a versatile, bi-directional, serial communication port. Electronically, this port can be configured for RS-422 multi-drop (loop), RS-422 full duplex (point-to-point, transmit/receive), or RS-485 half duplex (point-to-point, transmit then receive) operation. Selection is made via rear panel DIP switch positions 1-4 (see Figure 2-9).

After selecting the electrical interface, the port operating parameters must be entered using the flow diagram presented in Figure 6-1. Figure 6-2 (page 6-3) provides a full description of each (serial communication) parameter block depicted in Figure 6-1. Note that certain parameter entries are dependent upon the print format selection (accessed by pressing edit when SERIAL I/O is displayed). Standard LCp-100 indicators offer 3 formats; PRINT for output to a printer, CON'T (continuous) for constant output to a data logger, PLC, etc., and PC for full duplex interfacing with a more sophisticated host device. MODBUS, Fisher ProVox, and Allen-Bradley Remote I/O options will be discussed in Section X.

#### 6.2.1 Transmit Only Output Formats (ASCII)

Both the PRINT and CON'T ASCII output formats are transmit only. The print format is designed for use in conjunction with the front panel PRINT/COM key. Pressing the PRINT/COM key transmits all data strings that are selected 'YES' in Figure 6-1 (DISPLAY, GROSS, NET, ZERO, and TARE) to the printer. Table 6-1 shows the printer output format used for each transmitted data string.

The CON'T output string is defined in Table 6-2 (page 6-4). Continuous output transmissions occur at the time rate configure in Figure 6-1. Continuous outputs 'feed' weight data, status, and address information to a remote data logger or PLC type device without operator intervention.

**Table 6-1. Printer Output Transmission String**

#### Printout string:

<code>stx/adr/data/units/status/crlf</code>	
Defined:	
<code>stx....</code>	start of text character, hex 02
<code>adr....</code>	address, 3 ASCII chars: first two are '01'-'99' followed by an ASCII space
<code>data...</code>	weigh data 8 characters: 7 digits with decimal point or leading space; if msd is an ASCII minus '-' the data is negative
<code>abbreviated..</code>	two characters; first character is 'L','K','T','Z','G','N','K','L','S', or 'spaces' for pounds, kilograms,
<code>tons,</code>	ounces, grams, newtons, kilonewtons, liters,
<code>special,</code>	or null (space). second character is 'G','N','Z', or 'T' for gross, net, zero, or tare
<code>expanded ..</code>	ten characters; first three characters are a space plus a two character units abbreviation
<code>units</code>	'LB','KG','TN','OZ','GM','N','KN','L', or 4
<code>spaces</code>	for pounds, kilograms, tons, ounces, grams, newtons, kilonewtons, liters, or 4 user defined characters.
	the last seven characters are a space plus the data type spelled out with added spaces
<code>stat...</code>	'GROSS ',' NET ',' ZERO ', or ' TARE '
	one status character:
	' ' = everything ok,
	'M' = motion,
	'U' = a/d underload (signal below instrument capability),
	'V' = above overload limit,
	'O' = a/d overload (signal beyond instrument capability),
	'E' = load cell connect fault
<code>space...</code>	ASCII space, hex 20
<code>CRLF...</code>	carriage return linefeed two characters

# Analog and Serial Output Flow Diagram




Figure 6-1. Analog and Serial Communication Menu

### General Key Functions:

- ▲ Step back to previous menu selection.
- ▼ Advance to next menu selection.
- ENT Advance to next main menu selection.
- ESC Return to live operation from menu.
- ENT Change sub menu parameters.
- ENT Store displayed sub menu parameter in memory.

### To Enter/Alter a Numeric Value:

- ENT Press to initiate a change.
- ▲ Press to increment selected digit.
- ▼ Press to decrement selected digit.
- ▶ Press to advance to next digit.
- ◀ Press to return to previous digit.
- ENT Press to store selection in memory.

### To Enter/Alter a Parameter Selection:

- ENT Press to initiate a change.
- ▼ Press to view parameter options.
- ENT Press to store selection in memory.

# Serial Output Flow Diagram Block Explanations

<b>DISPLAY</b> YES • NO	Transmit current weight display (gross or net)	<b>STX</b> YES • NO	Typical leading character of any ASCII output data string
<b>GROSS</b> YES • NO	Transmit current gross weight value	<b>ADDRESS</b> YES • NO	Include designated address in output data string
<b>NET</b> YES • NO	Transmit current net weight value	<b>LEADING SPACES</b>	Choose either leading spaces or leading zeros in output string
<b>ZERO</b> YES • NO	Transmit current manual zero value	<b>UNITS EXPANDED</b>	Choose either no units, abbreviated units (2 characters), or expanded (10 character) units in printout
<b>TARE</b> YES • NO	Transmit current manual tare value	<b>UNITS</b> YES • NO	Include units in transmit string; units are abbreviated (2 characters)
		<b>STATUS</b> YES • NO	Include status character in output string
		<b>DELIMIT SPACE</b>	If more than one data selection (i.e. gross, net, tare) is requested, chose either a space or a carriage return/line feed (CRLF) to separate them
		<b>ENDCHAR CR CRLF</b>	Choose either a carriage return (CR) or a carriage return/line feed (CRLF) to end the output string
		<b>0.5 SECS CR DELAY</b>	If the printer does not have a character bufer, prevent data loss by selecting a delay time between carriage returns
		<b>TIMER</b> YES • NO	Choose whether or not to use a timed interval between continuous transmissions
		<b>59.9 SECONDS</b>	If YES chosen, select seconds portion of time interval
		<b>60 MINUTES</b>	If YES chosen, select minutes portion of time interval
<b>BOTH FORMATS</b>			
<b>CONTINUOUS OUTPUT FORMAT</b>			
<b>PRINTER OUTPUT FORMAT</b>			

Figure 6-2. Parameter Definitions

**Table 6-2. Continuous Output String Format**

**Tx string:**

sb/adr/data/units/status/crlf	
Defined:	
sb....	start of text character, hex 02
adr....	address, 3 ASCII chars: first two are '01'-'99' followed by an ASCII space
data...	weigh data 8 characters: 7 digits with decimal point or leading space; if msd is an ASCII minus '-' the data is negative
units..	two characters; first character is 'L','K','T','Z','G', 'N','K','L','S', or 'null' for pounds, kilograms, tons,
	ounces, grams, newtons, kilonewtons, liters, special, or null (space). second character is 'G', 'N','Z', or 'T' for gross, net, zero, or tare
stat...	one status character: ' ' = everything ok, 'M' = motion, 'U' = a/d underload (signal below instrument capability), 'V' = above overload limit, 'O' = a/d overload (signal beyond instrument capability), 'E' = load cell connect fault
space...	ASCII space, hex 20
CRLF...	carriage return linefeed two characters 0DH 0AH

Output string formats can be modified to accommodate custom interface requirements (Figure 6-1). Leading zeros can be replaced with ASCII spaces. STX (start of text), address, and instrument status can be omitted by selecting 'NO'. Units can be expanded or abbreviated in the print format and dropped altogether from the continuous format. Line feed can be deleted from the CRLF output or both characters can be replaced by an ASCII space. Figure 6-2 provides definitions for each parameter to assist in formatting custom output strings.

**6.2.2 Full/Half Duplex Bi-Directional Interface**

If PC output format is selected, units are capable of transmitting and receiving ASCII data strings. Table 6-3 (page 6-5) presents digit for digit data and syntax information for this interface.

Basically, the LCp-100 has 87 internal (EEPROM) registers which store all calibration, configuration, operation, and live weight data parameters. The PC format allows data in these registers to be read or re-written. By re-writing calibration span points (key-pad type calibration) and operating parameters, the LCp-100 can be quickly and completely reconfigured by a remote host device.

Several additional tables are provided to explain PC interfacing. Table 6-4 (page 6-7) provides examples of EEPROM reading/writing, and error code exchanges. Table 6-5 (page 6-8) demonstrates live weight transactions.

**6.2.3 Modbus Protocols (Optional)**

Refer to Section X for details concerning optional Modbus RTU and Modbus Plus protocol formatting.

**6.2.4 Fisher Rosemount - Provox Protocol (Optional)**

Refer to Section X for details concerning optional Provox protocol formatting and 20 mA current loop interface with a Fisher type CL6921 card.

**6.3 Allen-Bradley Remote I/O (Optional)**

The Allen-Bradley Remote I/O interface is fully defined in Vishay BLH technical manual # TM020. LCp-100/RIO wiring is defined in Section II, paragraph 2.3.7 of this manual.

**Table 6-3. Bi-Directional PC Interface Register Assignments**

**Note** - This is an ASCII interface. Requesting data from the LCC-II is done mainly by sending a 3 character command followed by a carriage return (ODH). These 3 character commands are listed under CODE in the following chart. The LCC-II's response to these commands is listed under RESPONSE. The response data is followed by a carriage return line feed (ODH,0AH).

There are also ways of stringing the commands together as shown in examples immediately following this chart.

**Note** - <00000000> represents weight data: # of zeros = number of digits. If there is a decimal point there will be one less digit. If the number is negative the most significant digit will be an ASCII minus '-' i.e. -500 will be '-<00000000>0500', -0.5 will be '-<00000000>00.5' is numeric data,<x.xxxxx> is mV/V data; if negative leading x = '-'.

**Note** - If unit address is selected, PC must transmit address code as 01A, 02A, etc. to establish communication

CODE	DEFINITION	RESPONSE	EXPLANATION
00;	A/D REV	00<1A>	1-9 = A/D TYPE, A-Z = REV
01;	SERIAL #	01<1234567>	1 = YEAR, 2-3 = WEEK, 4-7 = instrument number
02;	REF DATE	02<MMDDYY>	Month Day Year of mV/V cal
03;	mV/V ZERO CAL	03<x.xxxxx>	instrument mV/V zero cal point
04;	mV/V SPAN CAL	04<x.xxxxx>	instrument mV/V span cal point
05;	ZERO mV/V	05<x.xxxxx>	zero in mV/V
06;	SPAN1 mV/V	06<x.xxxxx>	span1 in mV/V
07;	SPAN1 units	07<00000000>	span1 in units
08;	SPAN2 mV/V	08<x.xxxxx>	span2 in mV/V
09;	SPAN2 units	09<00000000>	span2 in units
10;	SPAN3 mV/V	10<x.xxxxx>	span3 in mV/V
11;	SPAN3 units	11<00000000>	span3 in units
12;	SPAN4 mV/V	12<x.xxxxx>	span4 in mV/V
13;	SPAN4 units	13<00000000>	span4 in units
14;	SPAN5 mV/V	14<x.xxxxx>	span5 in mV/V
15;	SPAN5 units	15<00000000>	span5 in units
16;	SPAN6 mV/V	16<x.xxxxx>	span6 in mV/V
17;	SPAN6 units	17<00000000>	span6 in units
18;	SPAN7 mV/V	18<x.xxxxx>	span7 in mV/V
19;	SPAN7 units	19<00000000>	span7 in units
20;	SPAN8 mV/V	20<x.xxxxx>	span8 in mV/V
21;	SPAN8 units	21<00000000>	span8 in units
22;	SPAN9 mV/V	22<x.xxxxx>	span9 in mV/V
23;	SPAN9 units	23<00000000>	span9 in units
24;	SPAN10 mV/V	24<x.xxxxx>	span10 in mV/V
25;	SPAN10 units	25<00000000>	span10 in units
26;	# of SPAN POINTS	26<xx>	00 - 10
27;	CAL TYPE	27<x>	0 = QUICK, 1 = DEADLOAD, 2 = KEYPAD
28;	ENG UNITS	28<x>	0 = LB, 1 = KG, 2 = TN, 3 = OZ, 4 = GM, 5 = N, 6 = KN, 7 = L or 4 user defined characters
29;	CAPACITY	29<00000000>	sum of rated capacity of load cells
30;	DECIMAL POINT	30<x>	0 - 6 decimal point position 0 = none, 3 = 0.000
31;	RATED OUTPUT mV/V	31<x.xxxxx>	average of load cells rated output in mV/V
32;	UNIT COUNT BY	32<x>	0 - 6 = 1,2,5,10,20,50,100
33;	ZERO LIMIT	33<00000000>	keypad push to zero limit from cal zero, 0 = no limit
34;	OVERLOAD	34<00000000>	overload limit, 0 = no limit
35;	LEVEL CONFIG	35 <x>	level bar graph configuration 0 = off/gross, 1 = on/gross 2 = off/net 3 = on/net
36;	LEVEL 0%	36<00000000>	level 0% setting
37;	LEVEL 100%	37<00000000>	level 100% setting
38;	ARROWS CONFIG	38<x>	side arrows configuration 0 = off/gross, 1 = on/gross 2 = off/net 3 = on/net
39;	ARROWS 0%	39<00000000>	arrows 0% setting
40;	ARROWS 100%	40<00000000>	arrows 100% setting
41;	A1 ANNUNCIATOR	41<xx>	0-13: 7 = ser1 fram err
42;	A2 ANNUNCIATOR	42<xx>	0 = off 8 = analog fault
43;	A3 ANNUNCIATOR	43<xx>	1 = in motion 9 = analog over
44;	A4 ANNUNCIATOR	44<xx>	2 = zero lim 10 = analog under
45;	A5 ANNUNCIATOR	45<xx>	3 = overload 11 = rio status
46;	A6 ANNUNCIATOR	46<xx>	4 = ser1 rx 12 = modem rx
47;	A7 ANNUNCIATOR	47<xx>	5 = ser1 tx 13 = modem tx
48;	A8 ANNUNCIATOR	48<xx>	6 = ser1 par err
49;	ZERO KEY CONFIG	49<x>	0 = auto, 1 = manual
50;	TARE KEY CONFIG	50<x>	0 = auto, 1 = manual
51;	ANALOG CONFIG	51<x>	0 = gross, 1 = net
52;	ANALOG LOW	52<00000000>	low output weight setting
53;	ANALOG HIGH	53<00000000>	high output weight setting
54;	ANALOG LOW ADJUST	54<xxxx>	low analog output adjustment
55;	ANALOG HIGH ADJUST	55<xxxx>	high analog output adjustment

Table 6-3. Continued

56;	MANUAL ZERO	56<00000000>	manual zero
57;	MANUAL TARE	57<00000000>	manuai tare
58;	FILTER AVERAGING	58<x>	0 - 7 = 1,2,4,8,16,32,64,128
59;	FILTER BAND	59<xxxx>	0, 0.25 - 2.50, 3 - 100
60;	MOTION	60<xxxx>	0, 0.25 - 2.50, 3 - 50
61;	MOTION TIMER	61<x>	0 - 3 = 0.5, 1.0, 1.5, 2.0
62;	SECURITY LOCK	62,X.	0 = off, 1 = on
63;	PASSWORD	63<AAAAAAA >	security password 1-0,'-',',',A-Z
64;	MENU LOCKS	64<xxxxx>	0 = off, 1 = on; msd - lsd =diag,i/o,display,filter,cal
65;	KEY LOCKS	65 <xxxxx>	0 = off, 1 = on; msd - lsd =edit,print,g/n,tare, zero
66;	SERIAL 1 FORMAT	66<x>	0 = print, 1 = continuous, 2 = pc, 3 = MODBUS, 4 = ProVox
67;	SERIAL 1 ADDRESS	67<x>	0 - 99
68;	SERIAL 1 BAUD RATE	68<x>	0 = 9600, 1 = 19200, 2 = 300, 3 = 600, 4 = 1200, 5 = 2400, 6 = 4800
69;	SERIAL 1 PARITY	69<x>	0 = none, 1 = even, 2 = odd
70;	PRINT DATA	70<xxxxx>	0 = no, 1 = yes; msd - lsd = tare,zero,net,gross,display
71;	PRINT DATA FORMAT	71<xxxxxxx>	lsd = stx: 0/1 = no/yes 2sd = address: 0/1 = no/yes 3sd = leading 0s: 0 = spaces, 1 = zeros 4sd = units: 0 = no, 1 = abbreviated, 2 = expanded 5sd = status: 0/1 = no/yes 6sd = delimiter: 0 = space, 1 = crlf 7sd = terminating character:, 0 = crlf, 1 = cr
72;	PRINT CRLF DELAY	72<x.x>	0.0 - 9.9 seconds
73;	CON'T DATA	73<xxxxx>	0 = no, 1 = yes; lsd - msd =display,gross,net,zero,tare
74;	CON'T DATA FORMAT	74<xxxxxxx>	lsd = stx: 0/1 = no/yes 2sd = address: 0/1 = no/yes 3sd = leading 0s: 0 = spaces, 1 = zeros 4sd = units: 0/1 = no/yes 5sd = status: 0/1 = no/yes 6sd = delimiter: 0 = space, 1 = crlf 7sd = terminating character:0 = crlf, 1 = cr 8sd = timer: 0/1 = no/yes
75;	CON'T TX TIMER	75<xx.x>	00.0 - 59.9 seconds
76;	CON'T TX TIMER	76<xxx>	0 - 240 minutes
77;	TAG NO.	77<AAAAAAA>	cust tag no. 1-0,'-',',',A-Z
78;	CAL DATE	78<MMDDYY>	Month Day Year of calibration
79;	NEXT CAL	79<MMDDYY>	Month Day Year of next cal
80;	INSTRUMENT	84<xxxx>	instrument type: (0100) for LCc-II
81;	FIRMWARE VERSION	85<xxxx>	firmware version (1.00, 9020 etc)
82;	OPTIONS	86<xxxxxx>	[M] - [A] - [P] - [C] - [B] - [M]
VER	SOFTWARE VERSION	VER<x.xx>	1.00 - 9.99
OPT	OPTIONS	OPT<xxxxxx>	[M]-[A]-[P]-[C]-[B]-[M]
CLR	CLEAR	CALCLR	clear calibration
CAL	CALIBRATE		used to precede other commands

**Table 6-4. Read/Write and Error Code Examples**

**EEPROM data request examples:**

note - CRLF = carriage return = two ASCII characters 0D, 0A Hex  
 note - CR = carriage return = one ASCII character 0D Hex  
 note - using a dash between command numbers facilitates retrieving multiple parameters (see example #3).

1. to get span 1 mV/V value (code 06;)  

sent	received
06;CR	06<x.xxxxx>CRLF
2. to get span 1 mV/V and units values (code 06; and 07;)  

sent	received
06;07;CR	06<x.xxxxx>07<00000000>CRLF
3. to get complete analog output setup (codes 51; through 55;)  

sent	received
51-55;CR	5152<00000000>53<00000000>54<xxxx>55<xxxx>CRLF

**EEPROM data write examples:**

Note - Downloading data to the LCc-II is done by sending a 3 character command, the data enclosed in brackets <>, and a carriage return as shown in the examples below. The response will be staggered depending upon the time it takes to store the data. First the command will be returned and then after the data is stored the CRLF or next command will be returned.

1. to download capacity setting (code 29;), send (if capacity is 50000):  
 29<00050000>CR or 29<50000>CR  
 response will be: 29<00050000>CRLF
  2. to download display LEVEL bar graph settings (codes 35; 36; 37;), send (if tracking gross and 0% is 0 and 100% is 15000):  
 35<0>36<00000000>37<00015000>CR or 35<0>36<0>37<15000>CR  
 response will be: 35<0>36<00000000>37<00015000>CRLF
  3. to download zero and span 1 settings (codes 05; 06; 07;), send (if zero mV/V = 0.500000, span1 mV/V = 1.500000, span1 units = 20000):  
 05<0.500000>06<1.500000>07<20000>CR  
 response will be: 05<0.500000>06<1.500000>07<00020000>CRLF
  4. to acquire a new system zero (not download) (code 05;), send CAL05<0>CR:  
 The LCc-II will store the current mV/V value as a new system zero  
 response will be: immediately CAL then after zero is acquired: 05<x.xxxxx>CRLF
  5. to acquire a live deadload span 1 (code 07;), send (if span 1 = 2000.0) CAL07<2000.0>CR:  
 the LCc-II will store the current live (above system zero) mV/V level as span 1 mV/V value (code 06;) and store 2000.0 as the units value  
 response will be: immediately CAL, then after span is acquired: 07<0002000.0>CRLF
  6. to clear existing calibration send CALCLR CR:  
 If the LCc-II is in deadload or keypad cal all spans will be cleared, # of span points will be set to 0 and digital output will be based on system capacity and load cell mV/v output settings.  
 response will be: immediately CALCLR then after cal is cleared, CRLF.
- Note:** cal zero is not cleared by this command. If the LCc-II is in quick cal, response will be: CALCLR<NA>CRLF.

**INTERFACE ERROR CODES**

- NA = not allowed
- NT = no terminator
- LM = limit
- BF = input buffer overflow (too many characters sent, max is 255)
- AD = a/d error
- ? = unknown command

**ERROR CODE EXAMPLES**

sent	received	description
99,CR	99,?CRLF	unknown command
CR	?CRLF	unknown command
00<A1>CR	00<NA>CRLF	not allowed value for a/d rev
00<000>CR	00<NA>CRLF	not allowed value for a/d rev
28<5>CR	28<LM>CRLF	value limit for eng units
07<000050000>CR	07<NT>CRLF	no terminator (too many digits)

**Table 6-5. Live Data Transactions and Default Settings**

**LIVE DATA**

**Note:** - live weight data uses ( ) and not < as a frame, this is because the numerical part of the live weight data and stored eeprom data codes are the same number sequence 00 01 etc.

CODE	DEFINITION	RESPONSE	EXPLANATION
00,	GROSS	00(00000000)	current gross weight
01,	NET	01(00000000)	current net weight
02,	mV/V	02(x.xxxxxx)	current mV/V data
03,	LIVE mV/V	03(x.xxxxxx>)	current live mV/V data
04,	WEIGHT STATUS	04(A)	A = a/d status ( ) = normal (M) = motion (U) = signal underload (V) = above overload limit (O) = signal overload (E) = load cell connect fault A = analog output status
05,	ANALOG STATUS	05(A)	( ) = normal (U) = analog underrange (O) = analog overrange (E) = analog open circuit 0 - 65537 analog output
06,	ANALOG	06(XXXX)	upper display - alpha numeric with dp or leading space
07,	DISPLAY	07(ABCDEFGH IJKLMNOPQ R	lower display - alpha numeric with dp or leading space level - from left to right - = off @ = left arrow on A-Z = segments on + = right arrow on
		S	arrows- from bottom to top - = off @ = bottom arrow on A-I = arrows on + = top arrow on
		TU)	annunciators - A1,A2,A3,A4 = low 4 bits of T T = 1 0 0 0 0 0 0 A1 A2 A3 A4 for A1-A4 off T = @ (40 hex) if A3 is on T = B (42 hex)
			A5,A6,A7,A8 = low 4 bits of U U = 1 0 0 0 0 0 0 A5 A6 A7 A8 for A5-A8 off U = @ (40 Hex) if A6,A7 are on U = F (46 hex)
08	REMOTE INPUT	08(XXXXX)	lsb = freeze, all others = unused
09	PEAK DATA	09(00000000)	current peak data value
10	VALLEY DATA	10(00000000)	current valley data

**LIVE DATA REQUEST EXAMPLES**

1. to get gross weight (code 00,) if current gross weight is -10.1 lb  

sent	received
00,CR	00(-000010.1)CRLF
2. to get gross & net weights and status (codes 00, 01, 04,) if current gross weight is 440.05, tare value is 200.1 and scale is in motion:  

sent	received
00,01,04,CR	00(000440.05)01(000240.04)04(M)CRLF
3. to get live data codes 00 - 05 (data values used as example only):  

sent	received
00-05,CR	00(000440.05)01(000240.04)02(1.200505)03(0.800400)04(M)05( )CRLF

**Table 6-5. Continued**

**LIVE DATA CONVENIENCE COMMAND CODES**

code	definition	response	explanation
G	SWITCH TO GROSS	(per print format)	switch to gross and return current gross weight
N	SWITCH TO NET	(per print format)	switch to net and return current net weight
T	SWITCH TO NET & TARE	(per print format)	switch to net, tare, return current net weight
Z	SWITCH TO GROSS & ZERO	(per print format)	switch to gross, zero, return current gross weigh
P	CLEAR PEAK/ VALLEY DATA	(previous data)	clear peak and valley registers

**LIVE DATA CONVENIENCE COMMANDS (examples)**

1. to switch LCP-100 to gross mode and get gross weight (code G), if current gross weight is -10.1 lb, unit # is 01, and scale is in motion:

sent	received (according to print format setup)
GCR	01 -000010.1LGMCR LF

2. to switch LCP-100 to net mode, tare and get net weight (code T), if current gross weight is -10.1 lb, unit # is 01:

sent	received (according to print format setup)
TCR	01 000000.0LN CRLF



# SECTION VII

## System Diagnostics

### 7.1 OVERVIEW

LCp-100 diagnostics provide easy access to critical operating system data, and test/verification procedures for many indicator functions. Unique to LCp-100 diagnostics is the simulated weight or ramp feature.

Figure 7-1 (next page) presents the diagnostic flow diagram. Follow the procedures in this diagram to view values, set function limitations, test the front panel keypad, verify I/O functions, and run a simulated weightment.

#### 7.1.1 Diagnostic User

Diagnostic user provides three registers for storage of customer tag and calibration records. Users may enter a tag number, current calibration date, and projected date of next calibration, if desired.

#### 7.1.2 Diagnostic Version

Diagnostic version provides the software version, the installed option code derived from the ordering specification, the serial number, the A/D converter revision level, and the date of the factory calibration.

#### 7.1.3 Diagnostic Recall

Recall allows the operator to view current tare and zero values.

#### 7.1.4 Selecting Limits

DIAG LIMITS is accessed to enter/alter zero, overload, and motion limits and motion timer. The value entered for zero will limit the range of the front panel zero key (recommended 2-20%). Overload sets the alarm annunciator activate point. Motion determines how many counts must be exceeded before the 'in motion' alarm annunciator is activated. The motion timer determines how long the motion alarm remains activated after the motion condition is cleared.

#### 7.1.5 Front Panel Key Test

DIAG KEYPAD allows an operator to functionally test any/all front panel keys. **Press any two keys simultaneously to exit.**

#### 7.1.6 Check Remote Inputs

DIAG INPUTS is a check of all remote inputs. If inputs are inactive, their respective numbers will appear (54321). Once activated, the input number will change to a dash.

#### 7.1.7 Test/Verify The Analog Output

DIAG ANALOG tests the analog output. Test should be performed with a current meter attached. Testing firstly shows the actual analog count value being transmitted. Since the analog output is based on a 16 bit D-A conversion, the percent of span can be calculated by dividing the displayed counts by 65535. Secondly, any value may be entered to test the analog output. Enter a known value such as 65535 (max setting) and check current meter for appropriate output. Exiting this menu will automatically discontinue the test mode.

#### 7.1.8 Test/Troubleshoot The Serial Output

DIAG SERIAL provides the means to view both the transmit and receive buffers. After pressing EDIT, use the left/right arrow keys to increment forward or decrement backward through the selected buffer and view the hexadecimal value of each character. Using this procedure, incoming data requests can be checked for protocol/syntax accuracy and compared to LCp-100 output responses.

### 7.2 SIMULATING A WEIGHMENT

'Ramping' allows entry of starting and ending gross weight values, and then simulates a live weight addition without adding actual product/ingredients to the vessel. During the ramping exercise all outputs function as if an actual weight change were in progress.

DIAG RAMP allows entry of simulated starting (typically 0) and ending (typically full scale system capacity) weight points. Time for a complete ramp 'up' cycle (starting point up to ending point) can be selected from 1 to 240 seconds. Once ramp 'up' is complete, a ramp 'down' (ending point down to starting point) sequence automatically begins. At the BEGIN display, press EDIT to start ramping. Ramping will continue until ESC is pressed.

### 7.3 TEST/TROUBLESHOOT THE INTERNAL MODEM

DIAG MODEM allows evaluation of the modem transmit and receive buffers. See paragraph 7.1.8 for operational details.



# SECTION VIII

## Security System

### 8.1 INTRODUCTION

From password access to individually selectable menu and key 'locks', Safe-Weigh Software protects the entire weigh system from overt tampering or accidental data/configuration/calibration alterations. Figure 8-1 (next page) presents the security menu flow diagram. Follow the procedures designated to secure as many parameters as desired.

#### 8.1.1 Lock On/Off

Lock 'On' restricts access to the security menu and all other menus/keys designated as 'locked'. If locked, the designated password (see paragraph 8.2) must be entered to gain access to the security menu. Units are shipped with the lock 'Off' to allow initial configuration without a password.

#### 8.1.2 Menu Locks

Any or all of the LCp-100 main menus can be 'locked' to prevent parameter changes. To lock a menu, choose ON by pressing the EDIT and RIGHT arrow keys in sequence. Then press ENTER to store. Once a menu is designated as locked access to that menu is barred. To 'unlock' a locked menu, return to the security menu, enter the correct password, and change the status to OFF.

#### 8.1.3 Key Locks

Five of the LCp-100 front panel keys can be 'locked' to prohibit key function. Keys that can be locked are; ZERO, TARE, G/N (gross/net), PRINT, and EDIT. To lock a key, choose ON by pressing the EDIT and RIGHT arrow keys in sequence. Then press ENTER to store. If a key is designated as locked, it will not function when pressed. To 'unlock' a locked key, return to the security menu, enter the correct password, and change the status to OFF.

### 8.2 PASSWORD ACCESS

If lock ON is selected (paragraph 8.1.1), a password must be entered to regain access to the security menu. The following paragraphs explain how to select and enter a password. Once a password is chosen, it should be written down and stored in a confidential area.

#### 8.2.1 Selecting/Storing A Password

A password can be any combination of alpha-numeric characters up to seven digits long. It is not necessary to use all seven digits.

At the PASSWORD display, key in the designated characters using the arrow keys (LEFT/RIGHT to change digits, UP/DOWN to select character). When the password is correctly displayed, press ENTER to store.

#### 8.2.2 Entering The Password

If the lock is 'ON', the password must be entered to access the security menu. With the display reading SECURITY (a row of dashes above), press EDIT. Use the arrow keys to enter the complete password, as it was stored, on the row above SECURITY. When the correct password is displayed, press ENTER. Note that entering the password does not turn the lock off, it simply allows access to the security menu. If the lock is left ON, the password must be entered each time the security menu is accessed.

Master Password:

In addition to the user selected password there is also factory installed master password. If the user selected password is lost, contact any Vishay BLH service location for the master password.

# Security Menu Flow Diagram




Figure 8-1. Security Menu Functions

## SECTION IX Operation

### 9.1 GENERAL

LCp-100 indicator/transmitters power up in the gross weight weighing mode. If no system errors are detected, the front panel display will show the system live gross weight value. Note: For initial system power up, units are factory pre-calibrated with default values. Calibration (SECTION III), however, should be performed before attempting system operation.

Figure 9-1 presents the front panel switch functions for the operating mode. G/N toggles the operating mode from gross to net or net to gross. ZERO performs push to zero (gross mode) and TARE initiates the tare function in the net mode. PRINT/COM transmits the current weight status data to a printer if print format is selected. If the LCp-100 is connected to a host computer or PLC; gross, net, zero, tare, and print functions can be initiated remotely using the rear panel digital inputs.

### 9.2 GROSS WEIGHT WEIGHING

In the gross mode, all of the live weight of the system is displayed on the front panel. Live weight does not include the dead weight of a vessel or other mechanical equipment that is factored out during calibration.

### 9.3 ZERO OPERATION

A new zero can be acquired to compensate for changes in the dead load of the system due to heel build-up etc. Acquiring a new zero reference value does not affect the slope of the calibration. The push to zero range in the LCp-100 can be configured from OFF to 100% of system capacity (or 9999999). To prevent system overload, the zero selection limit usually does not exceed 20% of system capacity. Zero may be acquired only if the system is not in motion and the zero limit has not been exceeded.

### 9.4 NET WEIGHT WEIGHING

Net weight weighing is used when the operator wants to reset zero to compensate for the addition of live weight, or a container, before adding a specific amount of material. Tare is used to establish a zero reference in net mode.



Figure 9-1. Front Panel Operating Keys

### 9.5 TARE OPERATION

With the LCp-100 in net weighing mode, the tare function resets the output to zero. Push button taring (TARE key) allows the operator to achieve a new zero reference before addition of each ingredient so that errors do not become cumulative. If manual tare is selected, a tare value must be entered using the EDIT and arrow keys (press ENTER to store). Manual tare values typically represent the known weight of empty containers placed upon the scale/platform.

### 9.6 ERROR DETECTION AND CORRECTION

Should an error condition occur, a scrolling message will appear on the bottom line of the front panel display. As much as possible, messages define the exact error and suggest a remedy. Once the error is cleared, the scrolling message will stop and normal operation will resume. Table 9-1 presents all error messages with recommended solutions.

Table 9-1. Error Messages and Explanations

**POWER-UP FAULT MESSAGES**

<u>FAULT CONDITION</u>	<u>DISPLAY</u>	<u>REMEDY</u>
The a/d module does not have a revision number	NO A/D REV	Factory procedure
The a/d module does not have a mV/V calibration date	NO CAL DATE	Factory procedure
The a/d module does not have a temperature compensation reference	NO TMP COMP	Factory procedure
The a/d module does not have a mV/V calibration	NO mV/V CAL	Factory procedure
The instrument serial number has not been downloaded	NO SER NUMBER	Factory procedure
The instrument has not been calibrated for weight	NO CAL	Set to quick cal or Acquire deadload cal or Enter keypad cal
The instrument does not have a valid zero value	NO MAN ZERO	Acquire zero using zero key or enter manual zero
The instrument does not have a valid tare value	NO MAN TARE	Acquire tare using tare key of enter manual tare

**OPERATE MODE FAULT DISPLAYS**

Load cell excitation short, or no excitation	FAULT LOAD CELL scrolling message = "EXCITATION FAULT CHECK CONNECTIONS"	Check connections
Load cell excitation fault cleared	FAULT CLEARED	
A/D reference values out of limit	A/D FAULT followed by RESTART, followed by reset of instrument	Check connections, possible sense line open
Eeprom read/write failure when storing parameters	EEPROM ERROR	Contact field service
A/d output has reached maximum value	OVER RANGE	Check connections, excitation to signal short
A/d output has reached minimum value	UNDER RANGE	Check connections, excitation to signal short

**OPERATE MODE SPECIAL DISPLAYS**

Gross weight is equal to or greater than overload setting	5000 OVER LB (over is blinking)	
Attempt to enter locked menu or perform locked function	LOCKED	Go to security menu to unlock
Attempt to zero gross weight when in net mode	SWITCH TO GROSS	Switch to gross mode
Attempt to tare net weight when in gross mode	SWITCH TO NET	Switch to net mode
Attempt to zero gross weight at or above zero limit	ZERO LIMIT	
Attempt to zero gross weight or tare net weight in motion	IN MOTION	Wait for stable weight signal

# SECTION X

## Modem and Protocol Options

### 10.1 GENERAL

Section X provides information for LCp-100 interface and protocol options. Options such as the Service Link Modem, Modbus RTU, Modbus Plus, and Fisher Provox protocols are currently available. Fieldbus will be offered in the future.

### 10.2 THE SERVICE LINK MODEM

The LCp-100 modem is a V.22 bis data modem compatible with CCITT V.22 bis (2400 bps), Bell 212A (1200 bps), and Bell 103 (300 bps). It is programmed to answer a call after 1 ring. The originating modem should be set for 2400 baud using 8 data bits with no parity. Once connection is established, all data transfers follow the PC format presented in Section VI, Table 6-3.

When Vishay BLH Field Service is desired, contact the field service manager at (781) 821-2000 extension 216. The field service manager will arrange a diagnostic session, via modem, between the factory computer system and the installed LCp-100.

The Service Link Modem is currently operable only in the United States and Canada. Outside these territories, please contact the factory for assistance.

### 10.3 Modbus RTU PROTOCOL

This interface method is applicable to virtually any PC or other process control computer with Modbus RTU Master communication capability. The interface provides weight and diagnostic information and allows for remote control of tare, zero, and gross/net functions. New calibration data also may be downloaded via this interface. Information is transmitted in blocks of data, thereby minimizing polling and response time delays. The interface operates with the LCp-100 configured as the slave device and the host computer as the master. To initiate Modbus RTU protocol, simply select the Modbus print format as shown in Figure 6-1 (page 6-2). Modbus RTU uses the standard LCp-100 RS-485/422 communication port and requires no hardware alterations.

#### 10.3.1 Common Data Format

Table 10-2 presents a complete overview of Modbus register and bit allocations. Table 10-2 information which appears in conventional text applies to both Modbus RTU and Modbus Plus formats. Allocations which pertain only to Modbus Plus appear in *italic text*. In addition to Table 10-2 information, the following data formats and definitions are identical for both Modbus protocol options:

**Weight Data** - Two 16 bit signed integers, the first (high) integer must be multiplied by 32768 and then added to the second (low) integer.

**Status and setup parameters** - Two 16 bit unsigned integers.

**Alpha data** - For each register: high byte is first character, low byte is second character.

**NOTE:** If a decimal point is required the resulting value must be multiplied by the appropriate fraction, i.e., 0.01 for hundreds of a unit. In the case of mv/V values the multiplier is 0.000001. The LCp-100 range is (-999999/+999999).

**NOTE:** counts refers to displayed counts. If displayed weight is counting by 2 lb increments then presetting a register to 9 would mean 18 lbs.

#### 10.3.2 Modbus RTU Functions Supported

02 Read Input Status

03 Read Holding Registers

06 Preset Single Register

16 (10 Hex) Preset Multiple Registers

#### 10.3.3 Setup

Modbus RTU format, Device address, baud rate, and parity are all selectable under the SERIAL 1 section of the I/O MENU.

### 10.4 Modbus PLUS INTERFACE

Vishay BLH is an official ModConnect® Partner. As such, Vishay BLH has been authorized by Schneider Automation to incorporate Modbus Plus Communication Technology in its LCp-100 series product line. Modbus Plus protocol allows the LCp-100 to communicate on a peer-to-peer network link with Modicon 984 and Quantum PLC devices.

LCp-100 units equipped with the Modbus Plus option have a **custom rear panel with a specific MODBUS PLUS connector** (see Figure 10-2 and paragraph 10.4.3). The Modbus Plus interface does not use the standard LCp-100 RS-485/422 communication port.

#### 10.4.1 Routing Path Addressing

The LCp-100 Modbus Plus node is a Host Computer node with 8 data-slave input paths. When using Read/Write MSTR operations, or multiple Modbus Plus networks, take note of the message routing format. A routing address is five bytes in length. This allows communication between multiple Modbus Plus Networks over Bridge Mux hardware devices. Since the LCp is a host computer node, two of the five routing address bytes are required to identify it.

The next-to-last non-zero byte specifies the network node station address (1-64). The last non-zero byte specifies the input path or task number (1-8) to which the message is assigned. The other three routing address bytes allow communication through up to 3 Bridge Mux Devices. Table 10-1 depicts the address routing path for an LCp device at address 12, using path/task number 1.

Table 10-1. Routing Path Address Designations

Routing Path Example	Five Byte Address
No Bridge Mux Devices	12 - 1 - 0 - 0 - 0
Bridge Mux @ Address 26	26 - 12 - 1 - 0 - 0
1 <sup>st</sup> Bridge Mux @ Ad. 26, 2 <sup>nd</sup> Bridge Mux @ Ad. 28, 3 <sup>rd</sup> Bridge Mux @ Ad. 30	26 - 28 - 30 - 12 - 1

**NOTE:** If multiple devices access the same LCp, use a different task/path number for each requesting device. This will prevent address contention problems.

**NOTE:** Host device routing path format is different from PLC designated device addressing. When using PLC designated devices, the input path/task number is not required since it is automatically selected.

**NOTE:** Vishay BLH assumes reader/operator familiarity with Modbus Plus token passing network operation. Readers/operators unfamiliar with Modbus Plus should obtain the 'Modicon Modbus Plus Network Planning and Installation Guide' (GM-MBPL-001) and 'Modicon Ladder Logic Block Library User Guide' (840 USE 101 00) from the Schneider Corporation.


#### 10.4.2 Global Data Transfers

For high speed process control, Vishay BLH recommends that global data transfers be used. LCp-100 Global data allocations are defined in the Figure 10-1 parameter selection menu.

#### 10.4.3 Wiring and Node Addressing

Wiring is simply a matter of connecting the Modicon supplied, 9 pin D-type connector cable to the LCp-100 rear panel Modbus PLUS D-type socket mating half (see Figure 10-2).

LCp-100 nodes may occupy any station address location from 1 to 64. Selection is made at the rear panel (see table in Figure 10-2) DIP Switch designated ADDRESS. Add '1' to the switch selection to obtain the actual address (i.e., selection-0 +1 =1). DIP switch positions 7 and 8 are unused (see illustration, top of next column).



**NOTE:** Switch selections are read only during power-up. If the address selection is changed, the instrument must be powered down and then powered up again.

#### 10.4.4 Configuration

Figure 10-1 presents the Modbus Plus configuration menu. Parameters are as follows:

**ADDRESS** is non-configurable. It simply indicates that the network has recognized the LCp-100 device at the designated address.

**GLOBAL DATA** allows up to 10 words of live weight and status data to be selected for broadcast with each token pass. Each item selected represents two words of global data. The first item selected 'YES' becomes the first two words, the second 'YES' becomes words three and four, and so forth. The five available selections, status, gross weight, net weight, mV/V, and live mV/V are defined in Figure 10-1.

**ROTATION** is non-configurable. Rotation shows the time used for one complete token pass of all network nodes.

#### 10.4.5 Data Formatting

Table 10-2 presents a complete overview of Modbus register and bit allocations. Table 10-2 information which appears in conventional text applies to both Modbus RTU and Modbus Plus formats. Allocations which pertain only to Modbus Plus appear in *italic text*.


Vishay BLH offers two formats for actual data communication; double precision and Vishay BLH. Both formats are defined in the following sub-paragraphs. With both formats, two 16 bit status words (read only) supply system operating parameter information (see Table 10-3). To select the desired format, choose DOUBLE or Vishay BLH as depicted in Figure 10-1 Modbus Plus Parameter Selections. Note that double precision is the default format.

##### 10.4.5.1 Double Precision Format

Modicon Double Precision EMTH Functions allow PLC users to perform math functions in a 32 bit format. This is accomplished by combining data from two 16 bit registers. Each register holds a value in the range of 0 to 9999, for a combined Double Precision value in the range of 0 to 99,999,999. The combined value is referred to as operand 1.


The low-order half of operand 1 (register 1) is stored in the displayed register and the high-order half is stored in the implied register (register 2). Double Precision formatting, however, makes no provision for transmitting a data polarity indicator (plus or minus). Vishay BLH therefore, makes a slight format modification to transmit this vital statistic.

Double Precision data formatting uses two, 16 bit registers of information to transmit weight data (see below). Each register contains four significant digits. Since the most significant bit of register one is unused (always '0'), Vishay BLH uses this bit to transmit data polarity. If data is negative, this bit is set to a '1'. If data is positive (as assumed with conventional Double Precision format), this bit remains a zero. Upon receiving a data transmission, the polarity bit must be immediately evaluated. If data is negative (MSB = '1'), store the negative polarity bit in another PLC register (establish a negative data flag) and reset the MSB of register 1 to ZERO. Do not process the data in register 1 until the MSB is set to zero. Attempting to process data with the negative polarity bit set will result in erroneous information. Once the MSB of register 1 is confirmed to be zero, process data using conventional Double Precision EMTH instructions.



#### 10.4.5.2 Vishay BLH Data Format

Vishay BLH formatted weight data consists of two 16 bit signed integers, the first (high) integer must be multiplied by 32768 and then added to the second (low) integer (see below).



**NOTE:** If a decimal point is required the resulting value must be multiplied by the appropriate fraction, i.e. 0.01 for hundreds of a unit. In the case of mv/V values the multiplier is 0.000001. The LCP-100 range is (-999999/+999999).

**NOTE:** counts refers to displayed counts. If displayed weight is counting by 2 lb increments then presetting a register to 9 would mean 18 lbs.

#### 10.4.6 Flashing LED Status

A flashing green 'ACTIVE' LED located on the LCP-100 rear panel (Figure 10-2) indicates the status of Modbus Plus network operation. To interpret flash patterns, refer to the Modbus Plus Planning Guide (GM-MBPL-004).

**NOTE:** The rear panel LED flash patterns can be displayed on the LCP-100 front panel by configuring one of the Alarm/Status Annunciators for 'Modbus Plus Status' indication (see Section V).

#### 10.4.7 Manipulating The Front Panel Display

Provision has been made for the host PLC to display messages on the LCP-100 front panel display. Messages may occupy both the upper (7 character) and lower (8 character) display lines (Figure 10-3). To send a message, the host PLC transmits the message coded in conventional ASCII characters\* to registers 40258 thru 40265 along with a display control word; register 40257. Information written to these LCP-100 registers determines not only the message content but also the display time period. When the host message display time period expires, the LCP-100 will revert to its normal weight/status display. See Table 10-2 and Figure 10-3 for a detailed break-out of register allocations and functions.

Host messages displayed on the LCP front panel can be used to alert operators to error conditions, prompt required inputs, etc.

**NOTE:** Host messages are **not displayed** if the LCP-100 is in any calibration or parameter configuration menu mode.

\* To transmit a decimal point, set the 7th of the ASCII character byte to a '1'.

## 10.5 PROVOX PROTOCOL

This interface allows direct communication with a Fisher Rosemount CL6921 type external interface card (card must be configured for the 'Toledo' communication format). For further details, request Vishay BLH document TD-073.

### 10.5.1 Wiring

The Provox interface is transmit only and requires only a twisted pair of wires. Connect wires to the TxD+ and TxD- screw terminals on the 470294-1 interface converter board (supplied with this order) as shown in Figure 10-4. Plug the interface converter board into the LCp-100 rear panel serial port as shown in Figure 10-4. Set the SW1 DIP switches as shown in Figure 10-4. Note that the 470294-1 converter board supplied by Vishay BLH converts the LCp-100 output communication signal from RS-422 to 20 mA current loop for Provox operation.

The CL6921 external interface card input wiring pins are 17 (Rx-) and 18 (Rx+) as shown in Figure 10-4.

### 10.5.2 Configuration

To configure the LCp-100 for Provox communication, use the flow diagram presented in Figure 6-1. At the I/O serial display, simply press EDIT and select the Provox PRINT FORMAT. Once Provox format is selected, all parameters such as 4800 baud rate, string format, even parity, and transmission timing are automatically specified; no further parameter entries are needed.

### 10.5.3 Operation

With Provox format selected, the LCp-100 continuously transmits 18 bytes of information containing displayed and tare weight data to the external interface card at 4800 baud. This rate is pre-defined by Fisher Rosemount and cannot be changed. Each byte is 10 bit ASCII formatted as follows: bit 1 = start, bits 2-8 contain actual data, bit 9 = even parity, and bit 10 = stop. Table 10-4 presents the protocol for each of the 18 bytes.

Table 10-2. Modbus Register Allocations

REGISTER ADDRESSES

Registers 1 - 18 are read only, 20 - 136 are read/write, 256 is write only

REG#	DATA	REGS	DESCRIPTION
40001	SERIAL #	4	7 ASCII digits 0-9 starting with high byte of reg 40001 to high byte of reg 40004; reg 40004 low byte = 0
40005	SOFTWARE VER	1	number with 2 decimal places
40006	A/D REV	1	2 ASCII chars starting with high byte
40007	REF DATE	3	MMDDYY Month Day Year of internal cal; 6 ASCII digits 0-9 starting with high byte of reg 40007 to low byte of reg 40009
40010	STAT1	1	status register 1 (see page 10-7, Table 10-3 for def)
40011	STAT2	1	status register 2 (see page 10-7, Table 10-3 for def)
40012	GROSS WEIGHT	2	
40014	NET WEIGHT	2	
40016	mv/V ACTUAL	2	
40018	mv/V LIVE	2	
40020	ZERO	2	
40022	TARE	2	
40024	ZERO mv/V	2	zero cal point in mv/V
40026	SPAN1 mv/V	2	span1 cal point in mv/V
40028	SPAN1 units	2	span1 cal point in units
40030	SPAN2 mv/V	2	span2 cal point in mv/V
40032	SPAN2 units	2	span2 cal point in units
40034	SPAN3 mv/V	2	span3 cal point in mv/V
40036	SPAN3 units	2	span3 cal point in units
40038	SPAN4 mv/V	2	span4 cal point in mv/V
40040	SPAN4 units	2	span4 cal point in units
40042	SPAN5 mv/V	2	span5 cal point in mv/V
40044	SPAN5 units	2	span5 cal point in units
40046	SPAN6 mv/V	2	span6 cal point in mv/V
40048	SPAN6 units	2	span6 cal point in units
40050	SPAN7 mv/V	2	span7 cal point in mv/V
40052	SPAN7 units	2	span7 cal point in units
40054	SPAN8 mv/V	2	span8 cal point in mv/V
40056	SPAN8 units	2	span8 cal point in units
40058	SPAN9 mv/V	2	span9 cal point in mv/V
40060	SPAN9 units	2	span9 cal point in units
40062	SPAN10 mv/V	2	span10 cal point in mv/V
40064	SPAN10 units	2	span10 cal point in units
40066	# SPAN POINTS	1	0 - 10 (0 if no deadload or keypad cal)
40067	CAL TYPE	1	0 = QUICK, 1 = DEADLOAD, 2 = KEYPAD
40068	ENG UNITS	1	0 = LB, 1 = KG, 2 = TN, 3 = OZ, 4 = GM, 5 = K, 6 = KN, 7 = L
40069	CAPACITY	2	sum of rated capacity of load
40071	DECIMAL POINT	1	0-6 decimal point position: 0=none, 3=0.000
40072	RATED OUTPUT	2	average of load cells rated output in mv/V
40074	UNIT COUNT BY	1	0-6 = 1,2,5,10,20,50,100
40075	ZERO LIMIT	2	keypad push to zero limit
40077	OVERLOAD	2	overload limit, 0 = no limit
40079	LEVEL CONFIG	1	level bar graph configuration: 0 = off/gross, 1 = on/gross, 2 = off/net, 3 = on/net
40080	LEVEL 0%	2	level 0% setting
40082	LEVEL 100%	2	level 100% setting
40084	ARROWS CONFIG	1	side arrows configuration: 0 = off/gross, 1 = on/gross, 2 = off/net, 3 = on/net
40085	ARROWS 0%	2	arrows 0% setting
40087	ARROWS 100%	2	arrows 100% setting
40089	A1 ANNUNCIATOR	1	0 = off
40090	A2 ANNUNCIATOR	1	1 = in motion
40091	A3 ANNUNCIATOR	1	2 = zero lim
40092	A4 ANNUNCIATOR	1	3 = overload
40093	A5 ANNUNCIATOR	1	4 = ser1 rx
40094	A6 ANNUNCIATOR	1	5 = ser1 tx
40095	A7 ANNUNCIATOR	1	6 = s1 par err
40096	A8 ANNUNCIATOR	1	7 = s1 fram err
40097	ZERO KEY CONFIG	1	0 = auto, 1 = manual
40098	TARE KEY CONFIG	1	0 = auto, 1 = manual
40099	ANALOG CONFIG	1	0 = gross, 1 = net
40100	ANALOG LOW	2	low analog output weight setting
40102	ANALOG HIGH	2	high analog output weight setting
40104	ANALOG LOW ADJ	2	low analog output adjustment
40106	ANALOG HIGH ADJ	2	high analog output adjustment
40108	FILTER AVERAGING	1	0-7 = 1,2,4,8,16,32,64,128 conversions

**Table 10-2. Continued**

109	FILTER BAND	1	0-11 = 0-2.5 counts, 12-108 = 3-100 counts
110	MOTION	1	0-11 = 0-2.5 counts, 12-58 = 3-50 counts
111	MOTION TIMER	1	0 - 3 = 0.5, 1.0, 1.5, 2.0 seconds
112	PASSWORD	4	allowable ASCII chars are 0-9,A-Z, minus,
acc. Reg			
116	KEY/SECY LOCKS	1	40112 high byte is first char, reg 40115 high byte is last char, reg 40115, low byte set to 0 bits 0-4 = zero,tare,g/n,print,edit keys bit 5 = security lock; 0 = off, 1 = on
117	MENU LOCKS	1	bits 0-4 = cal,filter,display,i/o,diag menus; 0 = off, 1 = on
118	SERIAL 1 FORMAT	1	0 = print, 1 = continuous, 2 = pc, 3 = Modbus, 4 = Provox
119	SERIAL 1 ADDRESS	1	0 - 99
120	SERIAL 1 BAUD RATE	1	0 = 9600, 1 = 19200, 2 = 300, 3 = 600, 4 = 1200, 5 = 2400, 6 = 4800
121	SERIAL 1 PARITY	1	0 = none, 1 = even, 2 = odd
122	PRINT DATA SELECT	1	bits 0-4 = display,gross,net,zero,tare data; 0 = no, 1 = yes
123	PRINT DATA FRMAT	1	bits 0-1 = stx,address; 0 = no, 1 = yes bit 2 = leading 0s; 0 = spaces, 1 = zeros bit 4 = status; 0 = no, 1 = yes bit 5 = delimiter; 0 = space, 1 = crlf bit 6 = terminating char; 0 = crlf, 1 = cr bits 7,3 = units; 00 = no, 01 = abbreviated
124	PRINT CRLF DELAY	1	0-99 = 0.0 - 9.9 seconds
125	CONT DATA SELECT	1	bits 0-4 = display,gross,net,zero,tare data; 0 = no, 1 = yes
126	CONT DATA FRMAT	1	bits 0-1 = stx,address; 0 = no, 1 = yes bit 2 = leading 0s; 0 = spaces, 1 = zeros bit 3-4 = units,status; 0/1 = no/yes bit 5 = delimiter 0 = space, 1 = crlf bit 6 = terminating char; 0 = crlf, 1 = cr bit 7 = timer; 0 = no, 1 = yes
127	CONT TX TIMER	1	0-599 = 00.0 - 59.9 seconds
128	CONT TX TIMER	1	0-240 = 0 - 240 minutes
129	TAG NO.	4	allowable ASCII chars are 0-9,A-Z, minus, space. Reg 40129 high byte is first char, reg 40132 high byte is last char, reg 40132 low byte set to 0.
133	CAL DATE	3	MMDDYY Month Day Year of customer cal 6 ASCII digits 0-9 starting with high byte of reg 40133 to low byte of reg 40135.
136	NEXT CAL	3	MMDDYY Month Day Year of customer next cal. 6 ASCII digits 0-9 starting with high byte of reg 40136 to low byte of reg 40138
139	RIO BAUD RATE	1	0 =57.6K, 1 =115.2K, 2 =230.4K
140	RIO RACK #	1	0-63 = 1-77 octal
141	RIO QUARTER	1	0-3 = 1-4 starting quarter
142	RIO LAST RACK	1	0 =not last rack, 1 =last rack
143	INSTRUMENT	1	instrument type: 100 for LCP-100
144	OPTIONS	3	[M] - [A] - [P] - [C] - [B] - [M] 6 ASCII digits 0-9 starting with high byte of reg 40144 to low byte of reg 40146 0 = no, 1 = yes <b>bit 0 = status</b> <span style="float:right"><b>bit 4 = live mV/V</b></span> <b>bit 1 = gross</b> <span style="float:right"><b>bit 5 = spare</b></span> <b>bit 2 = net</b> <span style="float:right"><b>bit 6 = spare</b></span> <b>bit 3 = mV/V</b> <span style="float:right"><b>bit 7 = spare</b></span>
147	MB+ GLOBAL DATA	1 (bits 0-7)	
256	COMMAND	1	Write only register. 1 = tare net weight 2 = push to zero gross weight 3 = clear status register 1
257	CONTROL DATA	1	<b>if bit 0 = 1, apply data in registers 40258-40261 to upper display</b> <b>if bit 1 = 1, apply data in registers 40262-40265 to lower display</b> <b>if bit 2 = 1 and bit 0 =1, flash the upper display</b> <b>if bit 3 = 1 and bit 1 =1, flash the lower display</b> <b>bits 4-7 are spares, set to zero</b> <b>bits 8-15 are the display timer, each increment adds 50 msec</b> <b>i.e. 00000001 = 50 msec timer; 00000010 = 100 msec timer</b> <b>NOTE: 00000000 = 12800 msec timer (12.8 seconds)</b>
258-40261	UPPER DISPLAY DATA	4 registers	see Figure 10-3 for byte allocations
262-40265	LOWER DISPALY DATA	4 registers	see Figure 10-3 for byte allocations

**See Figure 10-3 for Display Data Register 40258 - 40265 Byte Allocations**

Table 10-3. Status Byte Bit Allocations

**STATUS REGISTERS**

Note: Status registers 1 & 2 are read only (function 03) registers. The bits in these registers can also be read as inputs 1 - 32 using function 02.

Note: In status register 1 the bits latch on if the condition is true. To clear status register 1, a 3 must be sent to command register 40256. In status register 2 the bits do not latch but follow the current status of the condition.



**(INPUT) STAT1 STATUS REGISTER 1**

(1)	BIT	0 - POWERUP
(2)	BIT	1 - UNABLE TO TARE/ZERO BECAUSE OF MOTION
(3)	BIT	2 - UNABLE TO ZERO BECAUSE OF LIMIT
(4)	BIT	3 - LOAD CELL SIGNAL UNDERRANGE
(5)	BIT	4 - LOAD CELL SIGNAL OVERRANGE
(6)	BIT	5 - LOAD CELL CONNECT FAULT
(7)	BIT	6 - ANALOG OUTPUT UNDERRANGE
(8)	BIT	7 - ANALOG OUTPUT OVERRANGE
(9)	BIT	8 - ANALOG OUTPUT OPEN CIRCUIT
(10)	BIT	9 - NO mV/V CAL
(11)	BIT	10 - NO ENGINEERING CAL
(12)	BIT	11 - NO TEMPERATURE COMPENSATION
(13)	BIT	12 - NO MANUAL ZERO
(14)	BIT	13 - NO MANUAL TARE
(15)	BIT	14 - EEPROM ERROR
(16)	BIT	15 - SPARE

**(INPUT) STAT2 STATUS REGISTER 2**

(17)	BIT	0 - POWERUP (on for 5 seconds after power up)
(18)	BIT	1 - UNABLE TO TARE/ZERO BECAUSE OF MOTION (on for 2 sec if true)
(19)	BIT	2 - UNABLE TO ZERO BECAUSE OF LIMIT ( on for 2 sec if true)
(20)	BIT	3 - LOAD CELL SIGNAL UNDERRANGE
(21)	BIT	4 - LOAD CELL SIGNAL OVERRANGE
(22)	BIT	5 - LOAD CELL CONNECT FAULT
(23)	BIT	6 - ANALOG OUTPUT UNDERRANGE
(24)	BIT	7 - ANALOG OUTPUT OVERRANGE
(25)	BIT	8 - ANALOG OUTPUT OPEN CIRCUIT
(26)	BIT	9 -
(27)	BIT	10 -
(28)	BIT	11 -
(29)	BIT	12 - MOTION
(30)	BIT	13 - FAULT (on if any bits on in status register 1)
(31)	BIT	14 - ZERO LIMIT
(32)	BIT	15 - OVERLOAD

# Modbus Plus Parameter Selections



## To Enter/Alter a Numeric Value:

- ENTR** Press to initiate a change.
- ▲** Press to increment selected digit.
- ▼** Press to decrement selected digit.
- ▶** Press to advance to next digit.
- ◀** Press to return to previous digit.
- ENTR** Press to store selection in memory.

## To Enter/Alter a Parameter Selection:

- ENTR** Press to initiate a change.
- ▼** Press to view parameter options.
- ENTR** Press to store selection in memory.

## General Key Functions:

- ▲** Step back to previous menu selection.
- ▼** Advance to next menu selection.
- ENTR** Advance to next main menu selection.
- ENTR** Return to live operation from menu.
- ENTR** Change sub menu parameters.
- ENTR** Store displayed sub menu parameter in memory.

\* This data also may be selected by writing to register 40147 bits 0-6 where bit 0=status, bit 1=gross weight, etc. Data formats for this exchange are defined in Table 10-2. Register locations are 40010 to 40019.

Figure 10-1. Modbus Plus Parameter Selections






Figure 10-2. LCp-100 Rear Panel - Modbus Plus Version

## LCp Upper Display Line



40258	40258	40259	40259	40260	40260	40261
High	Low	High	Low	High	Low	High
Byte						

## LCp Lower Display Line



40262	40262	40263	40263	40264	40264	40265	40265
High	Low	High	Low	High	Low	High	Low
Byte							

Figure 10-3. Display Write, Register and Byte Allocations




Figure 10-4. Fisher Provox Rear Panel Connections

**Table 10-4. 18 Byte Fisher Provox Protocol**

Byte 1: STX (02H)

Byte 2: Status Word A - Decimal Point Position or Dummy Zero Status

Bit	X00	X0	X	0.X	0.XX	0.XXX	0.XXXX	0.XXXXX
0	0	1	0	1	0	1	0	1
1	0	0	1	1	0	0	1	1

Byte 2: Status Word A - Count By Factor

Bit	Count By 1	Count By 2	Count By 5
3	1	0	1
4	0	1	1

5 - Always a "1"

Byte 3: Status Word B

Bit	Status - 0	Status - 1
1	Gross	Net
2	Positive	Negative
3	Not Overrange	Overrange
4	No Motion	Motion
5	Always a 1	
6	Normal Operation	Power Up

Byte 4: Status Word C - Bit 5 = 1, all other Bits = 0

Bytes 5-10: Indicated Weight Value

Bytes 11-15: Tare Weight Value

Byte 17: Carriage Return (0DH)

Byte 18: Checksum Character

\*Wiring designations based upon Vishay BLH's current understanding of the CL6921 board. Always consult with Fisher Rosemount to verify correctness of information.



# SECTION XI

## Profibus

This chapter defines the optional Profibus interface as it pertains to Vishay BLH LCp-100 instruments. Profibus, standardized in the European standard EN 50 170, is the operational network interface for Siemens PLC based control systems.

### 11.1 THE INTERFACE DEFINED

Consisting of three communication levels, the interface structure was designed for high-speed (up to 12 mbaud) communication between master (typically PLC) and slave devices.

#### 11.1.1 Profibus DP

Although three communication levels exist, LCp-100 units communicate only at the Profibus DP (decentralized periphery) level. At this level LCps are dedicated slaves with no master status or functionality. They cannot manipulate the bus or control token passes. They will respond quickly, however, to any master device on the network.

#### 11.1.2 GSD Files

GSD files are required to establish communication on the Profibus network. GSD files contain all device specific parameters such as supported baud rates, message lengths, I/O numbers, and diagnostic messaging. Vishay BLH supplies two GSD files on the accompanying diskette included with each order. Read the HINTSGSD.txt file contained on this diskette and load the appropriate GSD file into the master(s) network device.


### 11.2 INTERFACE WIRING

Figure 11-1 depicts the LCp-100 rear panel wiring arrangements. Simply connect a shielded, two-wire twisted pair cable to the PROFIBUS terminal. Cable shielding MUST BE connected at both ends to ensure proper operation. Vishay BLH recommends using a Siemens nine-pin, sub D connector with integrated termination (PN 6ES7972-0BA10-0XA0). If another connector is used, mandatory A and B signals must be accommodated as well as provision for termination, when required.

For reliable network operation, Vishay BLH recommends that the first and last network node be powered up at all times.

### 11.3 LCp-100 MENU CHANGES

With the Profibus option installed, parameter selections change in several menus. These changes override definitions and selections presented in earlier chapters of this manual.



**Figure 11-1. Profibus Rear Panel Connections**

### 11.3.1 I/O Menu Changes

With Profibus installed, other expansion slot A interfaces are disabled. Figure 11-2 shows the modified I/O menu with Profibus available rather than Modbus Plus or Allen-Bradley Remote I/O. Additional Profibus selections allow individual units to be reset or taken offline.




Figure 11-2. I/O Menu Changes

### 11.3.2 Diagnostic Menu Changes

Figure 11-3 presents changes to the diagnostic menu. Two added features define Profibus errors if they occur and current online/offline status.




Figure 11-3. Diagnostic Menu Changes

### 11.3.3 Display Menu Changes

See Figure 11-4 for alarm annunciator status changes. The Profibus status selection allows the lower rear panel LED activity to be mirrored on one of the eight annunciators. The lower LED indicates Profibus network status. Behavior of this LED is network specific and defined in Figure 11-4.




Figure 11-4. Display Menu Changes

## 11.4 DATA EXCHANGE FORMATS

LCP-100 Profibus input and output data formats consist of up to 8 bytes each as shown in Table 11-1. Each grouping of two bytes constitutes one 16-bit word.

**Table 11-1. Data Exchange Formats**

Input Data Format							
msg#	DataID	Status		Data Low		Data High	
Word 1	Word 2	Word 3	Word 4				
byte1	byte2	byte3	byte4	byte5	byte6	byte7	byte8
Output Data Format							
msg#	DataID	Command		Data Low		Data High	
Word 1	Word 2	Word 3	Word 4				
byte1	byte2	byte3	byte4	byte5	byte6	byte7	byte8

### 11.4.1 Input Data (LCP-100 Transmission)

The input data string is transmitted by the LCP-100 to the requesting master device. Each string consists of eight bytes and breaks down as follows:

#### Byte 1. Message #:

Message # is an echo of the first byte of the output data string (transmitted by the master). This is used by the master for data transfer verification.

#### Byte 2 Input data ID:

Data ID code as shown in Table 11-4.

#### Bytes 3 & 4. Status:

The Lcp100 operating status, each bit of the word made up of bytes 3 & 4 represents specific operating status. The descriptions of the bits are in Table 11-2. Bits 0 - 7 are in Byte 3, bits 8 - 15 are in Byte 4.

**Table 11-2. Status Word Definitions**

Status Word					
Bit Description	Decimal Point Position				
0	Decimal Point Posn. A	C	B	A	Posn.
1	Decimal Point Posn. B	0	0	0	0
2	Decimal Point Posn. C	0	0	1	0.0
3	Display Data A	0	1	0	0.00
4	Display Data B	0	1	1	0.000
5	Motion	1	0	0	.0000
6	Overload	1	0	1	.00000
7	Storing Data in EEPROM	1	1	0	.00000 0
8	Unable to Zero/Tare				
9	Download Address Error				
10	Download Data Error			Display Data	
11	4/20 Output Error		B	A	Dsply
12	A/D Underrange		0	0	Gross
13	A/D Overrange		0	1	Net
14	Excitation Fault		1	0	Spare
15	EEPROM Error		1	1	Spare

#### Bytes 5 - 8 (Words 3 & 4). Input data:

These two words contain the actual weight value (low word and then high word). Word 3, low word, is a 16 bit signed integer -32768 to 32767 with byte 5 being the low byte. Word 4, high word, is a 16 bit signed integer times 32768 with byte 7 being the low byte. If word 3 = 2 and word 4 = 1 the total data value would be 32770 (2 + 32768).

### 11.4.2 Output Data (from the Master)

Output data is transmitted to the LCP-100 by the requesting master. It consists primarily of command and ID data. ID data is defined in Table 11-4. Each string consists of eight bytes and breaks down as follows:

#### Byte 1. Message #:

Any number between 0 and 255 generated by the master and copied by the Lcp100 into the first byte of the input string. This is for host data transfer verification.

#### Byte 2 Output data ID:

When the Profibus master issues a download command, it must include the output data ID and the output data as well. Byte 2 of the Profibus output provides output data ID code as shown in Table 11-4.

#### Bytes 3 & 4 (Word 2). Command:

This command word is used by Profibus master to control Lcp100 (as a slave). The meanings of commands are shown in Table 11-3.

**Table 11-3. Profibus Master Command List**

Profibus Interface Commands	
Command ID	Description
0	Null Command
1	Switch to Gross
2	Switch to Net
3	Switch to Rate
4	Zero Gross Weight
5	Tare Net Weight
6	Download Data

#### Bytes 5 - 8 (Words 3 & 4). Output Data:

The third and fourth words of the Profibus output are low word and high word of the actual download data. Word 3, low word, is a 16 bit signed integer -32768 to 32767. Word 4, high word, is a 16 bit signed integer times 32768. See example in Inputs Words 3 & 4 definition. See Table 5 for ID codes and definitions of writable data.

**Table 11-4. Profibus Data ID Codes**

Type	ID Code	Data	Words	Description
Operate	0*	Gross Weight	2	System Gross Weight Value
Operate	1*	Net Weight	2	System Net Weight Value
Operate	2*	Spare	2	
Operate	3*	mV/V Actual	2	Input mV/V Signal
Operate	4*	mV/V Live	2	Live mV/V Signal (less dead weight)
Operate*	5	Zero	2	Keypad Push to Zero Value
Operate	6	Tare	2	Tare Value
Operate	7	Zero Limit	2	Keypad Push to Zero Limit
Operate	8	Overload	2	Overload Limit 0 = No Limit
Operate	9	Filter	2	Low Reg, Averaging 0-7 = 1, 2, 4, 8, 16, 32, 64, 128 Conversions High Reg, Band 0-10 = 0-2.5 counts, 11-108 = 3-100 counts
Operate	10	Motion	2	Low Reg, Motion Band 0=Off, 1-10=0-2.5counts, 11-58=3-50 counts High Reg, Motion Timer 0-3 = 0.5, 1.0, 1.5, 2.0 seconds
Operate	11	Zero Key Configuration	1	Low Reg, 0 = auto zero, 1 = manual zero
Operate	12	Tare Key Configuration	1	Low Reg, 0 = auto tare, 1 = manual tare
Cal	13	Zero mV/V	2	cal zero in mV/V
Cal	14	Span 1 mV/V	2	cal span 1 in mV/V
Cal	15	Span 1 Units	2	cal span 1 in units
Cal	16	Span 2 mV/V	2	cal span 2 in mV/V
Cal	17	Span 2 Units	2	cal span 2 in units
Cal	18	Span 3 mV/V	2	cal span 3 in mV/V
Cal	19	Span 3 Units	2	cal span 3 in units
Cal	20	Span 4 mV/V	2	cal span 4 in mV/V
Cal	21	Span 4 Units	2	cal span 4 in units
Cal	22	Span 5 mV/V	2	cal span 5 in mV/V
Cal	23	Span 5 Units	2	cal span 5 in units
Cal	24	Span 6 mV/V	2	cal span 6 in mV/V
Cal	25	Span 6 Units	2	cal span 6 in units
Cal	26	Span 7 mV/V	2	cal span 7 in mV/V
Cal	27	Span 7 Units	2	cal span 7 in units
Cal	28	Span 8 mV/V	2	cal span 8 in mV/V
Cal	29	Span 8 Units	2	cal span 8 in units
Cal	30	Span 9 mV/V	2	cal span 9 in mV/V
Cal	31	Span 9 Units	2	cal span 9 in units
Cal	32	Span 10 mV/V	2	cal span 10 in mV/V
Cal	33	Span 10 Units	2	cal span 10 in units
Cal	34	Number of Span Points	2	0-10, 0 = no eng cal
Cal	35	Cal Type	1	0 = quick, 1 = deadload, 2 = keypad
Cal	36	Eng Units	1	0 = lb, 1 = kg, 2 = tn, 3 = oz, 4 = gm
Cal	37	Capacity	2	sum of rated capacity of load
Cal	38	Decimal Point	1	0-6 = decimal point position, 0 = none, 6 = 0.000000
Cal	39	Rated Output mV/V	2	average of load cells rated output in mV/V
Cal	40	Unit Count By	1	0-6 = 1, 2, 5, 10, 20, 50, 100
Display	41	Display Powerup	1	0 = gross, 1 = net
Display	42	Level Config	1	Level bar graph: bit 0 = off, 1 = gross, 3 = net
Display	43	Level %	2	level % setting
Display	44	Level 100%	2	level 100% setting
Display	45	Arrows Config	1	side arrows: bit 0 = off, 1 = gross, 3 = net
Display	46	Arrows %	2	arrows % setting
Display	47	Arrows 100%	2	arrows 100% setting
Display	48	Annunciators A1	1	0 = off 8 = d/a fault
Display	49	Annunciators A1	1	1 = in motion 9 = d/a overrange
Display	50	Annunciators A1	1	2 = zero lim 10 = d/a underrange
Display	51	Annunciators A1	1	3 = overload 11 = Profibus status
Display	52	Annunciators A1	1	4 = serial RX 14 = spare
Display	53	Annunciators A1	1	5 = serial TX
Display	54	Annunciators A1	1	6 = parity
Display	55	Annunciators A1	1	7 = framing error

**Table 11-4. Profibus Data ID Codes (cont.)**

Type	ID Code	Data	Words	Description
Analog	56	Analog Config	1	0 = gross, 1 = net
Analog	57	Analog Low	2	low analog output weight setting
Analog	58	Analog High	2	high analog output weight setting
Analog	59	Analog Low Adjust	2	low analog output adjustment
Analog	60	Analog High Adjust	2	high analog output adjustment
Serial	61	Serial Format	1	0 = print, 1 = continuous, 2 = pc, 3 = modbus, 4 = provox
Serial	62	Serial Address	1	0 - 99
Serial	63	Serial Baudrate	1	0=9600, 1=19200, 2=300, 3=600, 4=1200, 5=2400, 6=4800
Serial	64	Serial Parity	1	0 = none, 1 = even, 2 = odd
Serial	65	Print Data Select	1	bits 0-5 = display, gross, net, zero, tare, spare
Serial	66	Print Data Format	1	bits 0-2: stx, address, leading 0s bit 4 = status bit 5 = delimiter: 0 = space, 1 = crlf bit 6 = terminating character: 0 = crlf, 1 = cr bits 7,3 = units: 00 = none, 01 = abbreviated, 10 = expanded
Serial	67	Print CRLF Delay	1	0 - 99 = 0.0 to 99 seconds
Serial	68	Con't Data Select	1	bits 0-5 = display, gross, net, zero, tare, spare
Serial	69	Con't Data Format	1	same as print format selection (65)
Serial	70	Con't TX Timer	2	low reg 0-599 = 0.00 to 59 secs, high reg 0-240 = 0 to 240 min
Reserved	71-122	Not Used At This Time		
Security	123	Password Upper 4	2	password upper 4 chars: ASCII 0-9, A-Z, minus or space
Security	124	Password Lower 3	2	password lower 3 chars: ASCII 0-9, A-Z, minus or space
Security	125	Key/Security Locks	1	bits 0-4 = zero, tare, g/n, print, edit keys - bit 5 = security lock
Security	126	Menu Locks	1	bits 0-4 = cal, filter, display, i/o, and diag menus
Security	127	Spare		
Instrument	128*	Serial # Upper 4	2	upper 4 digits of 7 digit ASCII numeric code (0-9)
Instrument	129*	Serial # Lower 3	2	lower 3 digits of 7 digit ASCII numeric code (0-9)
Instrument	130*	Software Version #	1	number with 2 decimal places (i.e. 100 = ver. 1.00)
Instrument	131*	A/D Rev.	1	2 ASCII characters
Instrument	132*	Ref Date Month/Day	2	upper 4 digits of 6 digit ASCII date code (MMDD) date format = MMDDYY month-day-year of internal cal
Instrument	133*	Ref Date Year	1	lower 2 digits of 6 digit ASCII date code (YY)
Instrument	134*	Instrument Model	1	100 = LCP-100
Instrument	135*	Options Upper 4	2	upper 4 digits of 6 digit ASCII option code [M]-[A]-[P]-[C]
Instrument	136*	Options Lower 2	1	lower 2 digits of 6 digit ASCII option code [B]-[M]
User	137	Tag Number Upper 4	2	upper 4 digits of 4 digit ASCII tag # - 0-9, A-Z, minus or space
User	138	Tag Number Lower 3	2	lower 3 digits of 4 digit ASCII tag # - 0-9, A-Z, minus or space
User	139	Cal Date Month/Day		
User	140	Cal Date Year	1	lower 2 digits of 6 digit ASCII date code (YY)
User	141	Next Cal Date Month/Day	2	upper 4 digits of 6 digit ASCII date code (MMDD) date format = MMDDYY month-day-year of internal cal
User	142	Next Cal Date Year	1	lower 2 digits of 6 digit ASCII date code (YY)
* Read Only Registers				